


EN

Operating instructions
Flow sensor CMM500
Compressor Master Meter
(for wet compressed air)



I. Foreword



Read these operating instructions carefully and completely before carrying out installation, commissioning and maintenance work. Follow the instructions to ensure safe operation and perfect functioning.

The operating instructions must always be available at the place of use. It is not permitted to provide only individual pages.



Office South/Sales Office South

Zindelsteiner Str. 15
D-78052 VS-Tannheim
Phone: +49 (0) 7705 978 99 0
Fax: +49 (0) 7705 978 99 20
Mail: info@cs-instruments.com
Web: <http://www.cs-instruments.com>

Sales Office North

Gewerbehof
D-24955 Harrislee
Phone: +49 (0) 461 807 150 0
Fax: +49 (0) 461 807 150 15
Mail: info@cs-instruments.com
Web: <http://www.cs-instruments.com>

Imprint

© CS Instruments GmbH & Co KG | 78052 VS-Tannheim | Zindelsteiner Straße 15 | GERMANY.
Translation of the original German manual CMM 500 | DE | V1.00.

II. Table of contents

I.. Foreword.....	2
II.. Table of contents	3
1.. Scope of delivery	5
2.. Type plate	5
3.. Device overview	6
4.. Pictograms and symbols.....	7
4.1... Warning symbols	7
4.2... Electrical symbols	7
5.. Signal words according to ISO 3864 and ANSI Z 535.....	7
6.. Intended use.....	8
7.. Inappropriate use	8
8.. Safety regulations	Fehler! Textmarke nicht definiert.
8.1... General safety instructions.....	Fehler! Textmarke nicht definiert.
8.2... Environmental protection	Fehler! Textmarke nicht definiert.
9.. Product information	12
9.1... Product features.....	12
9.2... Function	12
10 Technical data	13
10.1 Technical data and ambient conditions	13
10.2 Measuring range values	14
10.3 Dimensions	15
11 Installation preparations.....	16
11.1 Placement of the flow sensor, pipelines	16
11.2 Necessary inlet and outlet sections	16
12 Installation CMM 500.....	18
13 Electrical connection	19
13.1 Cable gland, permissible cable diameter.....	19
13.2 Wiring	19
13.2.1 General:	19
13.2.2 Power supply.....	19
13.2.3 Modbus RTU	20
13.2.4 Modbus TCP (Ethernet) Optional PoE*	21
13.2.5 Pulse output	21
13.2.6 MBus option	22
13.2.7 Option 2x 4...20mA (galvanically isolated)	22
14 Commissioning	24
14.1 Switch on sensor.....	24
14.2 Zero point adjustment	24


15 Operation CMM 500	25
15.1 Main menu (Home)	Fehler! Textmarke nicht definiert.
15.1.1 Initialization	Fehler! Textmarke nicht definiert.
15.2 Main menu after switching on.....	Fehler! Textmarke nicht definiert.
15.3 Settings menu	Fehler! Textmarke nicht definiert.
15.3.1 Sensor settings.....	Fehler! Textmarke nicht definiert.
15.3.1.1 Input pipe inside diameter.....	Fehler! Textmarke nicht definiert.
15.3.1.2 Entering / changing the consumption meter reading	Fehler! Textmarke nicht definiert.
15.3.1.3 Definition of units	Fehler! Textmarke nicht definiert.
15.3.1.4 Setting the reference conditions	Fehler! Textmarke nicht definiert.
15.3.1.5 Setting zero point and creep suppression	Fehler! Textmarke nicht definiert.
15.3.2 Modbus RTU	Fehler! Textmarke nicht definiert.
15.3.2.1 Setup.....	Fehler! Textmarke nicht definiert.
15.3.3 Modbus TCP (optional).....	Fehler! Textmarke nicht definiert.
15.3.3.1 Setup.....	Fehler! Textmarke nicht definiert.
15.3.3.2 Modbus Settings (2001...2005).....	Fehler! Textmarke nicht definiert.
15.3.3.3 Values register (1001 ...1500)	Fehler! Textmarke nicht definiert.
15.3.4 Pulse /Alarm.....	Fehler! Textmarke nicht definiert.
15.3.4.1 Pulse output	Fehler! Textmarke nicht definiert.
15.3.5 User settings.	Fehler! Textmarke nicht definiert.
15.3.5.1 password.....	Fehler! Textmarke nicht definiert.
15.3.5.2 Language	Fehler! Textmarke nicht definiert.
15.3.5.3 Display / Touch.....	Fehler! Textmarke nicht definiert.
15.3.6 Extended.....	Fehler! Textmarke nicht definiert.
15.3.7 4 -20mA.....	Fehler! Textmarke nicht definiert.
15.3.8 CMM 500 Info.....	Fehler! Textmarke nicht definiert.
15.4. MBus	Fehler! Textmarke nicht definiert.
15.4.1 Change communication values..	Fehler! Textmarke nicht definiert.
15.4.2 Coding VIF (Value Information Field).....	Fehler! Textmarke nicht definiert.
15.4.3 Basic communication settings ex works.....	Fehler! Textmarke nicht definiert.
15.4.4 Transmission values.....	Fehler! Textmarke nicht definiert.
16 Error messages	Fehler! Textmarke nicht definiert.
16.1 Error messages.....	Fehler! Textmarke nicht definiert.
17 Supplementary documentation	Fehler! Textmarke nicht definiert.

18 Declaration of conformity Fehler! Textmarke nicht definiert.

1 Scope of delivery


- CMM 500 flow sensor with venturi tube
- Calibration certificate
- These operating instructions

2 Type plate



- 1 - Manufacturer info
- 2 - Sensor name
- 3 - Order number, serial number, date
- 4 - 2D QR code
- 5 - Order code
- 6 - Warning "Operating instructions must be observed"
- 7 - Conformity/certification marking
8. Electrical connection data: e.g. available inputs and outputs, supply voltage

3 Device overview



- 1. Sensor housing with display
 - 2. Cable bushing (sensor cable inputs)
 - 3. Symbol PE / PE connection
 - 4. Housing with pressure measuring head
 - 5. Valve block with service and maintenance functions
 - 6. Temperature Sensor
 - 7. Measuring section / Venturi tube
 - 8. Button for selection menu item (>)
 - 9. ENTER/OK button
- S -- Flow direction

4 Pictograms and symbols

4.1 Warning symbols



General danger symbol (danger, warning, caution)



General note



Installation- and Instruction manual to consider (on Nameplate)



Installation- and Instruction manual to consider

4.2 Electrical symbols

Icon	Meaning
	Direct current
	Alternating current
	Direct and alternating current
	Earth connection An earthed terminal that is earthed from the user's point of view via an earthing system.
	Potential equalization connection (PE: Protective earth) Earthing terminals that must be earthed before other connections can be made.

5 Signal words according to ISO 3864 and ANSI Z 535

Danger!	Imminent danger As a consequence of incorrect handling: serious personal injury or death
Warning!	Possible hazard As a consequence of incorrect handling: possible serious injury or death
Caution!	Imminent hazard As a consequence of incorrect handling: possible personal injury or damage
Please note!	Possible hazard As a consequence of incorrect handling: possible personal injury or damage
Important!	Additional notes, information, tips As a consequence of incorrect handling: Disadvantages in operation and maintenance, no danger

6 Intended use

The CMM 500 (Compressor Master Meter) is a new type of reference flow meter that has been specially developed for high precision measurement of the delivery volume of compressors and for the billing of compressed air.

Areas of application: Directly after the compressor (wet side), at high temperatures (up to 100 °C) and/or fast processes (approx. 100 ms), for example for measuring the delivery volume of compressors, compressed air audits or for measuring the efficiency of compressed air systems.

It is also suitable for use both indoors and outdoors.

Improper or incorrect use the operational reliability will be canceled. The manufacturer is not liable for any damage resulting by improper or incorrect use.

Operation is only permitted in the following cases:

- The sensor must be protected from direct sunlight, rain, splashing water or excessive dust.
- Installation only downstream of a functioning water separator.
- In horizontal pipes (recommended) or in risers
- With an undisturbed flow pattern in compliance with the required calming distances upstream and downstream of the sensor.
- With correctly performed zero point adjustment and specification of the flow medium.
- Up to the maximum permissible differential pressure (500 mBar).
- In accordance with the technical data and approved ambient conditions.

7 Inappropriate use

Misuse when used as a climbing aid!

The flow sensor can be damaged. Risk of slipping. Select the installation location so that the flow sensor cannot be used as a climbing aid. Never use the flow sensor as a step or climbing aid.

Incorrect measurement results if installed in an incorrect position.

The flow sensor is not suitable for measuring leakage quantities.

8 Safety provisions

8.1 General safety instructions

Important notes for installation and maintenance personnel

The flow sensor may only be installed by trained specialists with knowledge and experience in compressed air and electrical engineering.

Electrical connection, commissioning and maintenance may only be carried out by qualified electricians in accordance with the electrotechnical regulations (DIN EN 50110-1, DIN EN 60204-1 and so on). Prerequisite: Technical training and knowledge of technical standards, EU directives and EU regulations.

Observe applicable national accident prevention regulations and ordinances. Observe measures of general occupational health and safety, such as through the wearing of suitable and prescribed personal protective equipment (PPE).

Only the manufacturer is permitted to perform repairs and adjustments.

Obligations of the installer and system operator

The flow sensor must be checked and maintained regularly by a trained and qualified individual.

Cleaning (the measuring obstacle if required) and maintenance intervals are to be determined by the system operator in accordance with DIN-ISO certification – frequency depending on ambient conditions and anticipated considerations.

Calibration: As part of the DIN ISO certification, have the flow sensor calibrated at regular intervals. The calibration cycles should be based on your internal specifications.

Remove the flow sensor for calibration and send to CS Instruments GmbH & Co.KG.

Keep an identical replacement sensor ready for use in systems that are essential for operation.



NOTE

▶ Without the consultation and approval of CS Instruments GmbH & Co.KG, the warranty claim is void in case of conversion work which is not listed in these operating instructions. This symbol is located at points in the operating instructions where special attention must be paid to ensure that the guidelines, regulations, instructions and the correct procedure for the work are observed and that damage and destruction are prevented.

Obligations of the installer of the system: The installer of the system is responsible for the safety of the system in which the VD 570 is installed. Pay particular attention to the technical data and ambient conditions (chapter 8) and the information on the electrical connection and prescribed connection cables (chapter 11).

Only use flow sensor VD 570 according to its intended purpose.

Risk of injury and accidents when operating outside the permissible ambient/operating conditions or operating temperatures due to overpressure or faulty installation. The pipeline pressure may be **up to 100 bar / 1450 psig** depending on the application. Ensure that the flow sensor is only operated within the permissible limit values (→ type plate, specified max. PS pressure) and that the measuring range full scales are taken into account (→ table chapter measuring range)

Risk of injury due to unauthorised unit modifications, incorrect installation or damaged components. The operating licence expires in these cases. **Operation is only permitted with original components.** Only operate the flow sensor when it is completely assembled. Do not operate a damaged sensor, and prevent further use of the sensor until it is repaired. The sensor must be checked and maintained regularly by trained and qualified individuals. Device modifications are not permitted and release the manufacturer from any warranty and liability.

Dirt particles in the compressed air will cause measurement errors. Dirt particles and liquids can contaminate the measuring tips of the sensor and lead to malfunction or failure. The system operator must ensure the prescribed purity of the fluids approved for the application as well as appropriate cleaning and maintenance intervals. The manufacturer provides no warranty and accepts no liability of any kind with regard to misuse.

Explosion hazard in potentially Ex-protective zones due to ignition of explosives when sparks are generated.

In Ex-protective zones please use the Sensor CMM 500 Ex.

Ensure clean compressed air without harmful components. Harmful components include explosive or chemically unstable gases and vapours, acid or base-forming substances such as ammonia, chlorine or hydrogen sulphide and condensates or oils and oil vapours.

Password protection for settings menu: Password protection is provided to protect against unauthorised entries/settings of the system parameters. For setting the password → chapter 13.3.5.1.

Danger of burns from hot sensor shaft. Hot air/gas/gas mixtures in the pipe can warm up or heat the sensor shaft of the flow sensor. Only touch the sensor shaft when it has cooled down. If applicable, use protective gloves.

Danger to life from escaping compressed air if it is directed at people, especially at high pressure. Shut off the compressed air line and check that it is depressurized. Ensure proper installation..

Danger if the applicable regulations for electrical installations are not observed. For electrical installation, observe the applicable regulations, e.g. DIN EN 50110-1. In Germany observe in particular VDE 0100 in the relevant parts. Observe local regulations. Before working on the electrical installation, switch off all supply circuits, switch off the mains fuse and secure against being switched on again. Ensure voltage-free status. Operate the flow sensor only with permissible connection cables for the mains supply and bus connection → technical data. Establish the electrical connection according to the wiring diagram (→ chapter 11).

Exercise due care when handling packaging materials. Comply with applicable safety and accident prevention regulations. Keep packaging material out of reach of children (choking hazard if small parts are swallowed).

Seals/sealants: As a suitable sealant for the screw connections of the ball valve or flow sensor, sealing rings made of copper or aluminium, elastomer sealing rings with metal backing, sealing tape/sealing cord or other equivalent sealants that meet the demands of the required, necessary compressed air quality can be used. For operating pressures >16 bar, generally use elastomer sealing rings with metal backing.

8.2 Environmental protection

The flow sensor and also the packaging contain recyclable materials that must not be disposed of in the residual waste. At the end of use, dispose of the packaging materials and flow sensor in an environmentally friendly manner in accordance with the regulations in your country.

The operating materials and auxiliary materials consumed and any parts that are replaced during operation of the flow sensor must be disposed of in accordance with environmental protection regulations.

Germany: Disposal code according to the Waste Catalogue Ordinance **(AVV) 16 02 14**, electrical and electronic devices and their components

9 Product information

9.1 Product features

The CMM 500 flow sensor is a consumption meter for gaseous fluids (air, nitrogen, etc.).

Advantages

- Integrated display with indication of flow rate, consumption, speed, temperature and pressure
- Units freely selectable: m³/h, m³/min, l/min, l/s, kg/h, kg/min, kg/s, cfm, bar, psi, °C or °F
- 2 buttons Input on the display (optical)
- Modbus RTU interface (RS-485)
- **Optional:** Ethernet interface (Modbus TCP) / PoE (Power over Ethernet)
- 1x analog output 4 ... 20 mA, adjustable for the measured variables flow rate, pressure, temperature or speed
- Switching/alarm output, galvanically isolated

9.2 Function

This flow sensor for compressed air measures the flow rate directly after the compressor, at high temperatures (up to 80 °C) and/or fast processes (100 ms).

The sensor control unit uses the mass flow rate to calculate the consumption data (based on the differential pressure in the Venturi pipe and the pipe diameter). The consumption data can be read out directly at the control unit, output at the analog output or transmitted to a control center via a bus system.

Important for a precise measurement result is an undisturbed flow pattern in compliance with the required calming distances in the measuring range → Chapter 11.

10 Technical data

10.1 Technical data and ambient conditions

Parameters	Flow rate, total consumption, pressure, temperature, speed
Sensor principle	Differential pressure
Measuring span	> 1:
Measuring range	0.04 ... 500 mBar Differential pressure for gases
Accuracy	± 1% for Qmin to 0.2 Qmax ± 0.5% for 0.2 Qmax to Qmax
typical Accuracy when installing CS inlet/outlet sections	± 0.75% for Qmin to 0.2 ± 0.3% for 0.2 Qmax to Qmax
Response time	T 99: < 1 second
Temperature of the medium	-20 ... 100 °C / -4... 212°F (Standard) -20 ... 85 °C / -4... 185 °F (Ex-Version)
Ambient temperature	-30 ... 70 °C / -22... 158 °F
Storage temperature	-40 ... 80 °C / -40 ... 176 °F
Pollution level	2
Relative humidity (transportation, storage, operation)	0% to 90% (non condensing)
Operating height, storage height	0...4000m (0...13123 ft).
Operating pressure	Max. 100 bar (1450 psig) at media temperature ≤100 °C
Compressed air requirements min.	ISO 8573-1 (particle moisture oil) 5-6-4
Pressure accuracy	0.5 % f. s. .** (at 20 °C / 68 °F)
Power supply	18 to 36 VDC via SELV supply, 5 W or Power over Ethernet in accordance with IEEE 802.3af, class 2 (3.84 ... 6.49 W). Fuse protection in supply unit T2.5L 125V If used at an altitude of over 2000 m, the power supply unit must also be approved for this altitude.
Power consumption	Max. 6.5W
Signal output	Modbus RTU (RS-485) 1x AO 4...20 mA (flow rate, pressure, temperature or speed) Optional: Modbus-TCP Ethernet / Etherneth PoE 2x 4..20mA gal. isolated
Measured values via Modbus TCP	Volume flow (m ³ /min, m ³ /h, cfm, ...) Meter reading (m ³ , cf, ...) Temperature (°C, °F)

	Pressure (bar, MPa, mbar, psi, ...) Air velocity (m/s, fpm)
Electrical connection	Via cable entry to internal
Protection class	IP 67

* based on ISO 1217 with 1000 mbar / 14.50 psi at 20 °C / 68 °F
 ** m.v. = from measured value | f. s. = from full scale


10.2 Measuring ranges

Restrictions:

Not suitable for measuring leakage rates

Measuring ranges Flow rate CMM 500 for compressed air (ISO 1217:1000 mbar, 20 °C)						
			Operating conditions 7 bar(g), 20 °C		Operating conditions 11 bar(g), 20 °C	
	Pipe inner diameter		Measuring range start and/or end values		Measuring range start and/or end values	
Custo ms	mm	DN	m³/h	cfm	m³/h	cfm
2"	54,5	DN 50	17...1800	11...1050	21...2240	12...1315
3"	82,5	DN 80	33...3475	20...2045	40...4300	23...2530
4"	107,1	DN 100	120...12800	70...7530	147...15900	86...9355
5"	135	DN 125	190...19950	111...11740	228...24750	134...14560
6"	159	DN 150	259...27700	152...16300	315...34350	185...20210
8"	200	DN 200	405...43560	238...25638	500...54050	294...31810

10.3 Dimensions



CMM 500					Flange DIN EN 1092-1 Type11 B1 PN 40			
Pipe size	L (mm)	L1 (mm)	H (mm)	H1 (mm)	B (mm)	Ø D (mm)	Ø K (mm)	n x ØL (mm)
DN 50	475	135	375,8	293,4	156	165	125	4 x 18
DN 80	475	135	407,6	307,7	156	200	160	8 x 18
DN 100	475	135	437,7	320,4	156	235	190	8 x 22

11 Installation preparations

11.1 Placement of the flow sensor, pipelines

- To ensure precise measurement results, the CMM500 must be installed correctly in the pipe.
- Only use correctly dimensioned seals that are suitable for the flow medium.
- Avoid diameter jumps in the pipe (inlet section) at the joints (max. 1 mm). For further information → ISO 14511:2019-01
- Observe the specified direction of flow → See the marking on the measuring section for the direction of flow.
- After the installation work, ensure that the piping is clean.
- Condensation or water droplets on the sensor element lead to incorrect measurement results. Therefore, do not install the flow sensor with the measuring tips pointing upwards or in downpipes.

11.2 Necessary inlet and outlet sections



NOTE

▶ The principle of differential pressure measurement used here is very sensitive to flow disturbances or turbulence. In order to maintain the accuracies specified in the data sheets, the sensor must be installed centrally in a straight piece of pipe at a point with an undisturbed flow path.

An undisturbed flow pattern is achieved if a sufficiently long section is provided upstream of the sensor (inlet section) and downstream of the sensor (outlet section) that is absolutely straight and without any disturbance points such as edges, seams, bends, etc.

When positioning the sensor, observe the necessary inlet and outlet distances. This is the only way to achieve precise measurement results.





NOTE

▶ The following figures show the minimum required lengths of the calming sections. If the distances are shortened, increased deviations in the measurement results must be expected → Avoid shortened distances.

Required inlet and outlet sections in the measuring pipe range

- Inlet and outlet sections ensure calm flow conditions and highly accurate measurements
- When installing the CS inlet and outlet sections, it is ensured that there is no turbulence due to different internal diameters, edges of the CMM 500 and inlet and outlet sections
- In the event of extreme pre-interference and turbulence, e.g. due to non-return flaps, valves, and partially closed ball valves, it is recommended to install a perforated plate rectifier upstream of the inlet section

CS Instruments inlet and outlet sections




Inlet/ outlet sections CMM 500			Flange DIN EN 1092-1 Typ11 B1 PN40		
Pipe diameter	Inlet section L - mm	Outlet section L - mm	ØD (mm)	ØK (mm)	n x ØL (mm)
DN 50	500	500	165	125	4 x 18
DN 80	800	500	200	160	8 x 18
DN 100	1000	500	235	190	8 x 22

12 Installation CMM 500

The CMM 500 sensor is supplied pre-assembled together with the measuring section.



- Installation by the customer is only permitted when the system is depressurized
- Ensure that the flow direction is correct.
- The tightness of the connections must be checked and ensured.



13 Electrical connection

Work on the electrical system may only be carried out by qualified electricians or authorized persons. For electrical installations, observe the applicable regulations, e.g. DIN EN 50110-1, in Germany in particular VDE 0100 with the corresponding parts or other national regulations accordingly.

13.1 Cable gland, permissible cable diameter

To ensure tightness and strain relief, connecting cables with the following cable diameters must be used

CMM 500 Standard permissible cable diameters : \varnothing 5- 9mm

CMM 500 Ex Permissible cable diameters: \varnothing 5-10mm


Tightening torque for the cap nut of the cable gland: 9 Nm

13.2 Wiring

13.2.1 In general:


- Only carry out wiring in a de-energized state.
- Minimize the length of the stripping
- Unused cable entries must be sealed with end caps
- Use of shielded connection cables
- Use of cables with cross-sections of $\geq 0.25\text{mm}^2$

13.2.2 Power supply



13.2.3 Modbus RTU

If the sensor is used at the end of the Modbus system, a termination is required. To do this, please connect the enclosed 120R resistor to the connections, pin 1 and pin 3 of connector "X2".




13.2.4 Modbus TCP (Ethernet) Optional PoE*

M12 x-coded

Data lines: 1,2 and 3,4


PoE lines: 5,6 and 7,8




Connection cable: Cat 6.

*PoE: Power over Ethernet


13.2.5 Pulse output



13.2.6 MBus option



13.2.7 Option 2x 4...20mA (galvanically isolated)



Plug	Pin	Description
X1 Supply voltage	1	VB - (negative supply voltage GND)
	2	VB+ (positive supply voltage)
X2 Modbus	1	Modbus (B)
	2	cable shield
	3	Modbus (A)
X3 Current output	1	I- Active
	2	I+ Active
X4 Direction / impulse	1	Pulse / Alarm *
	2	Pulse / Alarm *
	3	Directional input
	4	GND
X5 Current output 1	1	I- Active**
	2	I+ Active**
X6 Current output 2	1	I- Active**
	2	I+ Active**
K1 Mbus	1	Mbus
	2	Mbus

* All analog outputs are galvanically isolated.

** The analog current outputs X5 and X6 are optional (available as active and passive outputs).

14 Commissioning



WARNING

Danger from pressurized components.

- ▶ Ensure sufficient and safe compressed air quality with a pressure maintenance system. If the operating pressures are too low over a longer period of time, the flow velocity in the pipe increases significantly. This can lead to massive impairments in the compressed air treatment. Install a pressure maintenance system to avoid this.
- ▶ During initial commissioning, ensure that the operating pressure is matched to the consumer network.

14.1 Switch on sensor

1. Ensure that the flow sensor is connected correctly.
2. After the power supply is applied (initial start or after a reset), the CMM 500 flow sensor switches on and initializes the device for approx. 2...3 seconds.

14.2 Zero point adjustment

The CMM 500 flow sensor measures the flow velocity (differential pressure principle) in the Venturi tube.



In order to achieve the required measuring accuracy, the sensor must first be zeroed at the start of the measurement.

1. Apply system pressure to the sensor
2. Ensure that there is no flow.
3. Then start the zero point calibration on the sensor. → Chapter 13 "Operation".
4. The system can then be put into operation.




RECOMMENDATION

- ▶ Carry out zero point adjustment regularly (180 Tg) to ensure precise measurement results.

15 Operation CMM 500

Note: Only for version with display

The CMM 500 is operated using 2 optical buttons, which are operated directly via / through the glass cover. This means that the CMM 500 can be operated from the outside without opening the cover.



The individual menu items are selected using the ">" button and confirmed by pressing the "OK" button

Information or changes can be made in all fields with a white background; the selection for input is indicated by a yellow background color.

Words in *green* mainly refer to the figure(s) in the chapter section. But also important menu paths or menu items that are related to it are marked in *green letters*.

The menu navigation is generally in *green font*!

The table of contents and the chapter references in *blue font* contain links to the respective chapter headings.

15.1 Main menu (Home)

15.1.1 Initialization




After switching on the VD 570, the initialized screen is displayed followed by the main menu.

15.2 Main menu



Switching to pages 2-4 or back by pressing key „>“



AV-Time (Period for average value calculation) could be changed under *Sensor Setup.-Advanced- AV-Time*


15.3 Settings

The settings menu could accessed by pressing the key „OK“.
But the access to the *settings menu* is password protected.



Factory settings for password at the time of delivery: 0000 (4 times zero).


If required the password could be changed at *Setup–User setup-Password*.



Selection of a menu item or to change a value is done with the key „>“, a final move to the chosen menu item or takeover of the value change needs the confirmation by pressing the key „OK“

15.3.1 Sensor Setup

Setup → Sensor Setup



The screenshot shows a menu titled "Sensor Setup" with a blue header. The menu items are arranged in a list on the left, with their corresponding values on the right. The items are: "Diameter" (53.1 mm), "Total Counter" (0.00m³), "ZP Adjust" (----), and "Units". At the bottom, there are two buttons: "Ext. Setup" (highlighted in blue) and "Back".

Menu Item	Value
Diameter	53.1 mm
Total Counter	0.00m ³
ZP Adjust	----
Units	



For changes, first select the menu item with key „>“ and then confirm it with **“OK“**.

15.3.1.1 Input / change tube diameter

For CMM 500 not adjustable (suspended) as voted on included measuring section with corresponding pipe diameter.

15.3.1.2 Input / change consumption counter

Setup → Sensor Setup → Total Counter → Unit button



In order to change, e.g. the unit, first select by pressing key „>“ the button **“Unit”** and then key **“OK”**.

Select with the key „>“ the correct unit and then confirm selection by pressing 2x **„OK“**.


Entering / changing the consumption counter via button „>“, select the respective position and activate the position with the **„OK“**.

Important!

When the counter reach 10000000 m³ the counter will be reset to zero.

15.3.1.3 Definition of the units for flow, velocity, temperature and pressure





Setup → Sensor Setup → Units



To make changes to the unit for the respective measurement value, first select by pressing „>“ the field of the „measurement value“ and activate „it with **„OK“**.

Selection of the new unit with **„>“**

In case the quantity of units selectable are




15.3.1.4 Definition of the reference conditions

Here can be defined the desired measured media reference conditions for pressure and temperature and times for the filter and averaging.

- Factory pre-setting for reference temperature and reference pressure are 20 °C, 1000 hPa
- All volume flow values (m³/h) and consumption values indicated in the display are related to 20 °C and 1000 hPa (according to ISO 1217 intake condition)
- Alternatively 0 °C and 1013 hPa (=standard cubic meter) can also be entered as a reference.
- **Do not enter the operation pressure or the operation temperature under reference conditions!**


Setup → Sensor Setup → Advanced → Ref.Pref



In order to change, e.g. the unit, first select by pressing key „>“ the field **“Units”** and then key **“OK”**.

Select with the key „>“ the correct unit and then confirm selection by pressing 2x **„OK“**.

Setup → Sensor Setup → Advanced → Ref.Temp




Input / change of the value by selecting the respective position with button „>“ and entering by pressing button **„OK“**.

By pressing „>“ the position value is incremented by 1. Complete with **“OK”** and activate next number position.


15.3.1.5 Setting of Zeropoint and Low-flow cut off

Setup → Sensor Setup → ZP Adjust →




To make changes, first select a menu with button „>“ and confirm selection by pressing „OK“ .

Setup → Sensor Setup → ZP Adjust → ZeroPnt




If the sensor shows the message **CalZeroPnt** " on the display, a zero point calibration should be carried out, see also chapter 12.2 "Zero point calibration".

The zero point calibration must be carried out under system pressure and without flow




Setup → Sensor Setup → ZP Adjust → CutOff



With the low-flow cut off activated, the flow below the defined "LowFlow Cut off" value will be displayed as 0 m³/h and not added to the consumption counter.

For an input / change of the value select with the button „>“ the respective number position and activate it with „OK“.

Setup → Sensor Setup → ZP Adjust t → Reset



By selection of „Reset“ all settings for „ZeroPnt“ and „CutOff“ are reset.

Menu item to be select with button „>“ and confirm the reset with „OK“ .

15.3.2 Modbus RTU

15.3.2.1 Setup

The Flow sensors VD 570 comes with a Modbus RTU Interface.

Before commissioning the sensor the communication parameters

- Modbus ID, Baudrate, Parity und Stop bit

must be set in order to ensure the communication with the Modbus master.

Settings → Modbus Setup

*** ModBus Setup ***

ID	1	Baudrate	19200
Stop	1	Parity	even
Byte Order	ABCD		

Set to Default back

ID

2

CLR OK Cancel

*** ModBus Setup ***

ID	2	Baudrate	19200
Stop	1	Parity	even
Byte Order	ABCD		

Set to Default Save Cancel

For changes, e.g. the sensor ID, select with key „ Δ “ the field “ID” and then pressing “OK”.

Select the desired position by pressing the “>” and select with “OK” button.

Change values by pressing the „ Δ “ values takeover by pressing “OK”.

Inputs for baudrate, stopbit and parity is done analogue.

By means of the button "Byte Order" it

Default values out of factory:

Modbus ID:	1
Baud rate:	19200
Stopbit:	1
Parity:	even
Byte Order:	ABCD

Remark: If the sensor placed at the end of the Modbus system a termination is required. Therefore the enclosed 120R resistor is to be connected at Pin 1 and Pin 3 of connector „X2“

15.3.3 Modbus TCP (Optional)

15.3.3.1 Setup

The Flow sensors VD 570 comes optional with a Modbus TCP Interface (HW Interface:M12 x 1 X-coded connector).

Device supports with this option the Modbus TCP protocol for communication with SCADA systems. TCP port is set to 502 by default. Port can be changed at the sensor or using PC Service Software

Modbus device address (Unit Identifier) can be set in the range of 1- 247.

Specification and description of the Modbus protocol is free to download on: www.modbus.org.

Supported Modbus commands (functions):

Command	Code	Description
Function Code	3	(Read holding register)
Function code	16	(Write multiple registers)

For more details, please see **VA 5xx Modbus RTU_TCP Installation in the actual version**

Settings → Network Setup

Network	
IP Address:	192.168.001.002
Hostname:	VA_ETH_Simulation
MAC Address:	78:d8:00:40:00:00
<input type="button" value="IP Address"/> <input type="button" value="ModbusTCP"/>	
<input type="button" value="Back"/>	

15.3.3.1.1 Network Setup DHCP**Settings → Network Setup Settings → IP Address**

*** IP Address Setup ***	
DHCP	<input checked="" type="checkbox"/>
IP Address	192.168.172.010
Subnet	255.255.255.000
Gateway	192.168.172.001
<input type="button" value="Advanced"/> <input type="button" value="Save"/> <input type="button" value="Cancel"/>	

Here you can set up and made a connection, with or without *DHCP*, to a computer.

Remark:

With activated *DHCP* the automatic integration of the sensor in an existing network is possible, without a manual configuration.

Storing of settings by pressing "**Save**"

15.3.3.1.2 Network Settings static IP

Settings → Network Setup Settings → IP Address → IP Address

Settings → Network Setup Settings → IP Address → Subnet

Settings → Network Setup Settings → IP Address → Gateway

*** IP Address Setup ***

DHCP

IP Address 192.168.172.010

Subnet 255.255.255.000

Gateway 192.168.172.001

Advanced back

*** IP Address Setup ***

DHCP

IP Address 192.168.172.010

Subnet 255.255.255.000

Gateway 192.168.172.001

Advanced back

IP Setup

1 9 2

CLR back

Subnet Setup

2 5 5

CLR back

Gateway Setup

1 9 2

CLR back

*** IP Address Setup ***

DHCP

IP Address 192.168.172.011

Subnet 255.255.255.000

Gateway 192.168.172.001

Advanced Save Cancel

For manual (static) IP, the "IP Address", "Subnet" and "Gateway" selection keys must be selected and activated with "OK".

The first data field of the selection, in this case the IP address, is then marked (red).

Confirm with "OK" the corresponding input menu is opened.

By means of ">", the next data field is changed.

Store the settings by „Save“

15.3.3.1.3 Modbus TCP Settings

Settings → Network Setup Settings → IP Address → MB TCP

*** MB TCP ***	
ID	5
Port	502
Byte Order	ABCD
Set to Default	back

Settings → Network Setup Settings → IP Address → ID

Settings → Network Setup Settings → IP Address → Port

Modbus TCP UI	
	5
CLR	back

Modbus TCP Port	
	502
CLR	zurück

For changes, e.g. the sensor ID, select with key „>“ the field **“ID”** and then pressing **“OK”**.

Select the desired position by pressing the **“>”** and select it with **“OK”** button.

Change values by pressing the **“>”** values takeover by pressing **“OK”**.

Input for the port is done analogue.

By means of the button **“Byte Format”** it is possible to change the data format (Word Order). Possible formats are **“ABCD”** (Little Endian) and **“CDAB”** (Middle Endian)

Saving the changes by pressing **“Save”**, therefore select it with key **“>”** and then confirm it with **“OK”**.

Reset to the default settings by activating **“Set to Default”**-

15.3.3.2 Modbus Settings (2001...2005)

Modbus Register	Register Address	No. of Byte	Data Type	Description	Default Setting	Read Write	Unit /Comment
2001	2000	2	UInt16	Modbus ID	1	R/W	Modbus ID 1...247
2002	2001	2	UInt16	Baudrate	4	R/W	0 = 1200 1 = 2400 2 = 4800 3 = 9600 4 = 19200 5 = 38400 6 = 57600 7 = 115200
2003	2002	2	UInt16	Parity	1	R/W	0 = none 1 = even 2 = odd
2004	2003	2	UInt16	Number of Stopbits		R/W	0 = 1 Stop Bit 1 = 2 Stop Bit
2005	2004	2	UInt16	Word Order	0xABCD	R/W	0xABCD = Big Endian 0xCDAB = Middle Endian

Values Register (1001 ...1500)

Modbus Register	Register Address	No. of Byte	Data Type	Description	Default	Read Write	Unit /Comment
1101	1100	4	Float	Flow in m ³ /h		R	
1109	1108	4	Float	Flow in Nm ³ /h		R	
1117	1116	4	Float	Flow in m ³ /min		R	
1125	1124	4	Float	Flow in Nm ³ /min		R	
1133	1132	4	Float	Flow in ltr/h		R	
1141	1140	4	Float	Flow in Nltr/h		R	
1149	1148	4	Float	Flow in ltr/min		R	
1157	1156	4	Float	Flow in Nltr/min		R	
1165	1164	4	Float	Flow in ltr/s		R	
1173	1172	4	Float	Flow in Nltr/s		R	
1181	1180	4	Float	Flow in cfm		R	
1189	1188	4	Float	Flow in Ncfm		R	
1197	1196	4	Float	Flow in kg/h		R	
1205	1204	4	Float	Flow in kg/min		R	
1213	1212	4	Float	Flow in kg/s		R	
1221	1220	4	Float	Flow in kW		R	

Modbus Register	Register Address	No.of Byte	Data Type	Description	Default	Read Write	Unit /Comment
1269	1268	4	UInt32	Consumption m ³ before comma	x	R	
1275	1274	4	UInt32	Consumption Nm ³ before comma	x	R	
1281	1280	4	UInt32	Consumption ltr before comma	x	R	
1287	1286	4	UInt32	Consumption Nltr before comma	x	R	
1293	1292	4	UInt32	Consumption cf before comma	x	R	
1299	1298	4	UInt32	Consumption Ncf before comma	x	R	
1305	1304	4	UInt32	Consumption kg before comma	x	R	
1311	1310	4	UInt32	Consumption kWh before comma	x	R	
1347	1346	4	Float	Velocity m/s			
1355	1354	4	Float	Velocity Nm/s			
1363	1362	4	Float	Velocity Ft/min			
1371	1370	4	Float	Velocity NFt/min			
1419	1418	4	Float	GasTemp °C			
1427	1426	4	Float	GasTemp °F			

Remark:

For DS400 / DS 500 / Handheld devices - Modbus Sensor Datatype

„Data Type R4-32“ match with „Data Type Float“

For more additional Modbus values please refer to VA5xx_Modbus_RTU_TCP_Installation_in the actual version.

15.3.4 Pulse /Alarm

Setup → Sensor Setup→ Pulse/ Alarm

The galvanically isolated output can be defined as pulse- or alarm output. Selection of field „**Relay Mode**” with key „>“ and change modus by pressing key „**OK**“.

For alarm output following units could be chosen: kg/min, cfm, ltr/s, m³/h, m/s, °F, °C and kg/s.

„**Value**“ defines the Alarm value, „**Hyst.**“ defines the desired hysteresis and with „**Hi-Lim**“ or „**Lo-Lim**“ the alarm settings when the alarm is activated

Hi-Lim: Value over limit

Lo-Lim: Value under limit

15.3.4.1 Pulse output

The maximum frequency for pulse output is 50 pulses per second (50Hz).

The Pulse output is delayed by 1 second.

Pulse value	[m³ /h]	[m³ /min]	[l/min]
0.1 ltr / Pulse	18	0,3	300
1ltr / Pulse	180	3	3000
0.1m³ / Pulse	18000	300	300000
1 m³ / Pulse	180000	3000	3000000


Table 1 Maximum flow for pulse output

Entering pulse values that are not allow a presentation to the full scale value, are not allowed. Entries are discarded and error message displayed.

15.3.5 User Setup

15.3.5.1 Password

Settings → *UserSetup* → *Password*




To make changes, first select a menu with button „>“ and confirm selection by pressing „OK“.

It is possible to define a password. The required password length is 4 digits. Please select with button „>“ a figure and confirm it with „OK“. Repeat this 4 times.

With „<“ the last figure could be deleted. Password input have to be inserted twice.

15.3.5.2 Language

Settings → *UserSetup* → *Language*





Currently 4 languages have been implemented and could be selected with button „>“.

Change of language by confirming with „OK“.

15.3.5.3 Display / Touch

Settings → *UserSetup* → *Display / Touch*




With the button „-“ and with button „+“ it is possible to adjust the backlight / display brightness. The actual / adjusted backlight brightness is showed in the graph „*Backlight.*“

By activation “*Dimming after*” and entering a time a display dimming could be set.

With „*Rotate Screen*“ the display information could be rotated by 180°.

15.3.6 Advanced


Settings → *Advanced*



By pressing „*Factory Reset*“ the sensor is set back to the factory settings.




15.3.7 4 -20mA

Settings → 4-20mA



To make changes, first select a menu with button „>“ and confirm selection by pressing „OK“.

Settings → 4-20mA → Channel 1



The 4-20 mA Analogue output of the Sensor VD 570 can be individually adjusted.

It is possible to assign following values „Temperature“, „Velocity“ und „Flow“ to the channel CH 1.

To make changes, first select the value item with button „>“ and confirm.




Moving between the different measurements values or to deactivate the 4-20mA with setting to „unused“ by pressing „OK“.

To the selected measurement value a corresponding / appropriate unit needs to be defined. Select „Unit“ with „>“ and open menu with „OK“.

Select required unit with „>“ and take over by pressing „OK“.

Here e.g. for the measurement value Flow, procedure for the other measurements values is

Settings → 4-20mA → Channel 1 → AutoRange



The scaling of the 4-20mA channel can be done automatically "Auto Range = on" or manual "AutoRange = off" .


With button „>“ select the menu item „AutoRange“ select with „OK“ the desired scaling method. (Automatically or manually)

In case of **AutoRange = off** with „Scale 4mA“ und „Scale 20mA“ the scale ranges needs to be defined.

Select with button „>“ the item „Scale 4mA“ or „Scale 20mA“ and confirm with „OK“ .

Input of the scaling values will be analogous as described before for value settings.

Settings → 4-20mA → Error Current



This determines what is output in case of an error at the analog output.

- 2 mA Sensor error / System error
- 22 mA Sensor error / System error
- None Output according Namur (3.8mA – 20.5 mA)
 < 4mA to 3.8 mA Measuring range under range
 >20mA to 20.5 mA Measuring range exceeding

To make changes first select a menu item "Current Error" with button „>“ and then select by pressing the „OK“ the desired mode

Remark:

Default setting VD 570 for analogue output is

Default settings for VD 570 with option board analogue output

For max. flow see label on Sensor.

Channel 1:0...max. flow [m³/h]

Channel 1:0...max. flow [m³/h]

Channel 2: -20°C ... 100°C]

15.3.8 VD 570 Info

Setup → Sensor Setup → Info

*** Info ***	
Production Datas	
Serial No.:1234567890	Details
Cal. Date: 10.01.2013	
Sensor Datas	
Sensor Type: IST 1.8	
Max Speed: 92,7 m/s 600m³/h	
Max Temp: 100.0 °C	
Live Datas	
Run Time: 2d 21h 23m 12s	
Vin: 23,8V	Temp: 35,8
Options	Back

*** Calibration Details ***	
Calibration Conditions	
Ref. Pressure:	1000.00mbar
Ref. Temperature:	20 °C
Cal. Diameter:	53,1 mm
Cal. Pressure:	6000.00mbar
Cal. Temperature:	23 °C
Cal. Points:	10
Back	

Here you get a brief description of the sensor data incl. the calibration data.

Under *Details*, you are able to see in addition the calibration conditions.

15.4 M-Bus

15.4.1 Change of communication settings

The communication settings Primary-address and baud rate could be changed directly at the sensor, in case sensor has a display, or with the PC Service software (Order-No. 0554 2007).

Settings → M-Bus

*** Settings ***	
Sensor Setup	4 - 20mA
ModBus Setup	M-Bus
Pulse/Alarm	
User Setup	Info
Advanced	Back to Main

Settings → M-Bus → Adr

Possible inputs are values from 1-255 (Default setting = 1)

*** M-Bus ***	
Adr	1
Baudrate	2400
ID	123456
<input type="checkbox"/> Units as String	
back	

Primary Address	
1	
CLR	back

Settings → M-Bus → Baudrate

Possible values are 2400, 4800 and 9600 Baud (Default setting = 2400).

*** M-Bus ***	
Adr	1
Baudrate	2400
ID	123456
<input type="checkbox"/> Units as String	
back	

With „>“ select the button „Adr“ and confirm it with „OK“.

Select the desired position by pressing the button „△“ and select it with "OK" button.

Change values by pressing „>“ with step of 1, taking the value by confirming with "OK".

Move to next position with „>“

Using „CLR“ clears up the complete settings at once.

For saving the changes done press button „Save“ to discard the changes press button

Baudrate change by pressing the button „OK“

For saving the changes done press button „Save“ to discard the changes press button „Cancel“.

Leaving the menu with „Back“.

15.4.2 Coding VIF (Value Information Field)

*** M-Bus ***

Adr 1 Baudrate 2400

ID 123456

Units as String

back

*** M-Bus ***

Adr 1 Baudrate 2400

ID 123456

Units as String

Save Cancel

The Sensor offers two possibilities for coding the Value Information Field (VIF).

- Primary VIF (The units and multiplier correspond to M-Bus specification 4.8 chapter 8.4.3)
- Plain Text VIF ((units are transmitted as ASCII characters. So units that are not included in M-Bus specification chapter 8.4.3 are possible)

Download:

<https://m-bus.com/downloads>

15.4.3 Default Settings communication

Primary Address*:	1
ID:	Serial number of Sensor
Baud rate*:	2400
Medium*:	depending on medium (Gas or Compressed Air)
Manufacturer ID:	CSI
VIF coding:	Primary VIF

Both addresses, Primary address and ID, could be searched in the M-Bus system automatically.

15.4.4 Default values transmitted

Value 1 with [Unit]*:	Consumption [m ³]
Value 2 with [Unit]*:	Flow [m ³ /h]
Value 3 with [Unit]*:	Gas temperature [°C]


*All Values could be changed / preset in production or with CS Service software (Order-No. 0554 2007)

16 Error messages

16.1 Errors messages

- Low Voltage**
 Bei einer Versorgungsspannung kleiner 18V wird die Warnmeldung „**Low Voltage**“ angezeigt. Dies bedeutet der Sensor kann nicht mehr ordnungsgemäß arbeiten / messen und somit stehen keine Messwerte für Durchfluss, Verbrauch sowie Geschwindigkeit zur Verfügung.
- Internal Error**
 In the case of this "**Internal Error**" message, the sensor has detected an internal read error on e.g. EEPROM, AD converter etc..
- Temp out of Range**
 If the media temperature is outside the specified temperature range, the status message status message "**Temp out of Range**". This leads to incorrect measured values (outside the sensor specification)
- Low Voltage 4-20mA**
 For sensors with a galvanically isolated 4-20mA output, a minimum supply voltage of 17.5V is required. If the voltage falls below this, the error message "**Low Voltage 4-20mA**" is displayed

Error messages:



17 Supplementary Documentation

- Supplementary Documentation for Ex-Version:

Flow / Consumption Sensor CMM 500 Ex-Documentation

18 DECLARATION OF CONFORMITY

KONFORMITÄTSERKLÄRUNG

DECLARATION OF CONFORMITY

Wir CS Instruments GmbH & Co. KG
We Zindelsteinerstr. 15, 78052 VS-Tannheim

Erklären in alleiniger Verantwortung, dass das Produkt
Declare under our sole responsibility that the product

Verbrauchs-/ Durchflusssensor CMM 500
Flow Sensor CMM 500

den Anforderungen folgender Richtlinien entsprechen:
We hereby declare that above mentioned components comply with requirements of the following EU directives:

Elektromagnetische Verträglichkeit Electromagnetic compatibility	2014/30/EU 2014/30/EC
RoHS (Restriction of certain Hazardous Substances)	2011/65/EC & 2015/863/EC

Angewandte harmonisierte Normen:


Harmonised standards applied:

EMV-Anforderungen EMC requirements	EN 55011:2016 + A2:2021-04 EN 61326-1: 2013-07
RoHS (Restriction of certain Hazardous Substances)	EN IEC 63000:2018

Das Produkt ist mit dem abgebildeten Zeichen gekennzeichnet.
The product is labelled with the indicated mark.



Harrislee, den 22.04.2024


Wolfgang Blessing Geschäftsführer