



EN

Operating Instructions

Flow Sensor VD 550

(for wet compressed air)

T-Nr.:

I. Foreword



Read these operating instructions carefully and completely before installation, commissioning and maintenance work. Follow the instructions to ensure safe operation and proper functioning.

The operating instructions must always be available at the place of use. It is not permissible to make only individual pages available.



CS INSTRUMENTS GmbH & Co. KG

Sales Office South / Geschäftsstelle Süd/

Zindelsteiner Str. 15

D-78052 VS-Tannheim

Tel.: +49 (0) 7705 978 99 0

Fax: +49 (0) 7705 978 99 20

Mail: info@cs-instruments.com

Web: <http://www.cs-instruments.com>

Sales Office North / Geschäftsstelle Nord

Gewerbehof 14

D-24955 Harrislee

Tel.: +49 (0) 461 807 150 0

Fax: +49 (0) 461 807 150 15

Mail: info@cs-instruments.com

Web: <http://www.cs-instruments.com>

Impressum

© CS Instruments GmbH & Co.KG | 78052 VS-Tannheim | Zindelsteiner Strasse 15 | GERMANY.
Translation of the original German instructions. VD 550 | DE | V1.00

II. Table of contents


I.	Foreword	2
II.	Table of contents	3
1	Scope of delivery	5
2	Type plate	5
3	Device overview	6
4	Pictograms and Symbols	7
4.1	Warning Symbols	7
4.2	Electrical symbols	7
5	Signalwords according ISO 3864 and ANSI Z 535	7
6	Intended use	8
7	Use contrary to the intended purpose	8
8	Safety provisions	9
8.1	General safety instructions	9
8.2	Environmental protection	11
9	Technical data	12
9.1	Technical data and ambient conditions	12
9.2	Signal circuits	13
9.2.1	Modbus	13
9.2.2	Current output	13
9.2.2.1	Active	13
9.2.2.2	Passive	13
9.2.3	Impulse	13
9.2.4	Alarm	13
9.3	Dimensions VD 550	14
9.4	Measuring ranges flow rate VD 550	15
9.4.1	Measuring range end values „224 m/s“	16
9.4.2	Measuring range end values „600 m/s“	17
10	Installation / Assembly	18
10.1	Placement of the flow sensor, pipelines	18
10.2	Necessary inlet and outlet sections	18
10.3	Inlet / outlet sections	19
10.4	Installation VD 550	20
10.4.1	½" welded nipple with ball valve	20
10.4.2	Spot drilling collar with ball valve	20
10.5	Installation of the sensor	21
10.5.1	Mounting the VD 550 in the ball valve	21
10.5.2	Installation instructions	21
10.6	Installation angle for installation locations with potential water incidence	23
10.7	Alignment of housing / display	24

11	Commissioning	25
11.1	Sensor switch on	25
11.2	Zero point adjustments	25
12	Connection diagram	26
12.1	Cable glands - clamping ranges	26
12.2	Wire connection	26
12.2.1	General:	26
12.2.2	Power supply	26
12.2.3	Modbus RTU:	26
12.2.4	Modbus TCP (Ethernet) Optional PoE	27
12.2.5	Pulse Output	27
12.2.6	Option MBus	28
12.2.7	Option 2x 4..20mA (galv. getrennt)	28
13	Operation VD 550	30
13.1	Main menu (Home)	31
13.1.1	Initialization	31
13.2	Main menu after switching on	31
13.3	Settings	32
13.3.1	Sensor Settings	33
13.3.1.1	Input / change tube diameter	33
13.3.1.2	Input / change consumption counter	34
13.3.1.3	Definition of the units for flow, velocity, temperature and pressure	34
13.3.1.4	Definition of the reference conditions	35
13.3.1.5	Setting of Zeropoint and Low-flow cut off	36
13.3.2	Modbus RTU	37
13.3.2.1	Setup	37
13.3.3	Modbus TCP (Optional)	38
13.3.3.1	Setup	38
13.3.3.1.1	Network Setup DHCP	38
13.3.3.1.2	Network Settings static IP	39
13.3.3.1.3	Modbus TCP Settings	40
13.3.3.2	Modbus Settings (2001..2005)	41
13.3.3.3	Values Register (1001 ... 1500)	41
13.3.4	Pulse /Alarm	43
13.3.4.1	Pulse output	43
13.3.5	User Settings	44
13.3.5.1	Password	44
13.3.5.2	Language	44
13.3.5.3	Display / Touch	45
13.3.6	Advanced	45
13.3.7	4 -20mA	46
13.3.8	VD 550 Info	48
13.4	MBus	49
13.4.1	Change of communication settings	49
13.4.2	Coding VIF (Value Information Field)	50
13.4.3	Default Settings communication	50
13.4.4	Default values transmitted	50
14	Error messages	51
15	Supplementary Documentation	51
16	Declaration of Conformity	52

1 Scope of delivery


- Flow sensor VD 550
- Alignment wrench
- Calibration certificate
- These operating instructions

2 Type plate



- 1 - Manufacturer info
- 2 - Sensor name
- 3 - Order number, serial number, production date
- 4 - 2D QR code
- 5 - Order code
- 6 - Warning "Operating instructions must be observed"
- 7 - Conformity/certification marking
8. Electrical connection data: e.g. available inputs and outputs, supply voltage

3 Device overview



1. Sensor case with Display (345° rotatable)
2. Cable gland (Sensor cable input))
3. Pressure sensors case
4. Flock nutr
5. Shaft with scaling
6. -Button for selection menu item (>)
7. ENTER-/OK button
8. PE Symbol / - connection

4 Pictograms and Symbols

4.1 Warning Symbols



General Warning symbol (Danger, Warning, Caution)



General note



Installation- and Instruction manual to consider (on Nameplate)



Installation- and Instruction manual to consider

4.2 Electrical symbols

Symbol	Meaning
	DC Current
	AC Current
	DC- and AC Current
	Earth connection An earthed terminal that is earthed from the user's point of view via an earthing system..
	Potential equalization connection (PE: Protective earth) Earthing terminals that must be earthed before other connections can be made.

5 Signalwords according ISO 3864 and ANSI Z 535

Danger!	Imminent danger As a consequence of incorrect handling: serious personal injury or death
Warning!	Possible hazard As a consequence of incorrect handling: possible serious injury or death
Caution!	Imminent hazard As a consequence of incorrect handling: possible personal injury or damage
Note!	Possible hazard As a consequence of incorrect handling: possible personal injury or damage
Important!	Additional notes, information, tips As a consequence of incorrect handling: Disadvantages in operation and maintenance, no danger

6 Intended use

The VD 550 consumption sensor is used for continuous flow measurement based on a dynamic pressure/differential pressure measurement.

The VD 550 can be configured to measure a predefined selection of pure gases or gas mixtures.

Consumption measurement of gases such as air (also wet compressed air), technical gases etc. as well as explosive gases such as natural gas, methane, propane and hydrogen with ATEX approval.

It can furthermore be used both indoors and outdoors.

Improper or unintended use may jeopardize operational safety. The manufacturer is not liable for any damage arising from this.

Zulässig ist ein Betrieb nur in folgenden Fällen:

- Installation only behind a functioning water separator.
- In horizontal lines (recommended) or in risers
- With undisturbed flow in compliance with the required calming sections upstream and downstream of the sensor.
- With precise positioning of the measuring tips of the sensor on the centre of the pipe.
- With correctly aligned sensor at angular deviation not exceeding 2° (recommended installation position with 15° inclination to the horizontal).
- With the zero point adjustment made correctly, the inner diameter set and the flow medium specified.
- Up to the maximum permissible flow velocity -See type plate
- According to the technical data and approved ambient conditions.
- With correct calibration

7 Use contrary to the intended purpose

Misuse when used as a climbing aid! The flow sensor can be damaged. Danger of slipping. Select the installation location so that the flow sensor cannot be used as a climbing aid. Never use the flow sensor as a step or climbing aid.

The flow sensor is not suitable for measuring leakage rates.

8 Safety provisions

8.1 General safety instructions

Important notes for installation and maintenance personnel

The flow sensor may only be installed by trained specialists with knowledge and experience in compressed air and electrical engineering.

Electrical connection, commissioning and maintenance may only be carried out by qualified electricians in accordance with the electrotechnical regulations (DIN EN 50110-1, DIN EN 60204-1 and so on). Prerequisite: Technical training and knowledge of technical standards, EU directives and EU regulations.

Observe applicable national accident prevention regulations and ordinances. Observe measures of general occupational health and safety, such as through the wearing of suitable and prescribed personal protective equipment (PPE).

Only the manufacturer is permitted to perform repairs and adjustments.

Obligations of the installer and system operator

The flow sensor must be checked and maintained regularly by a trained and qualified individual.

Cleaning (the measuring obstacle if required) and maintenance intervals are to be determined by the system operator in accordance with DIN-ISO certification – frequency depending on ambient conditions and anticipated considerations.

Calibration: As part of the DIN ISO certification, have the flow sensor calibrated at regular intervals. The calibration cycles should be based on your internal specifications.

Remove the flow sensor for calibration and send to CS Instruments GmbH & Co.KG. Keep an identical replacement sensor ready for use in systems that are essential for operation.



NOTE

▶ Without the consultation and approval of CS Instruments GmbH & Co.KG, the warranty claim is void in case of conversion work which is not listed in these operating instructions. This symbol is located at points in the operating instructions where special attention must be paid to ensure that the guidelines, regulations, instructions and the correct procedure for the work are observed and that damage and destruction are prevented.

Obligations of the installer of the system: The installer of the system is responsible for the safety of the system in which the VD 550 is installed. Pay particular attention to the technical data and ambient conditions (chapter 7) and the information on the electrical connection and prescribed connection cables (chapter 10).

Only use flow sensor VD 550 for its intended purpose.

Risk of injury and accidents when operating outside the permissible ambient/operating conditions or operating temperatures due to overpressure or faulty installation. The pipeline pressure may be **up to 100 bar/1450 psig** depending on the application. Ensure that the flow sensor is only operated within the permissible limit values (→ type plate, specified max. PS pressure) and that the measuring range full scales are taken into account (→ table in the appendix). In **application areas >16 bar/>232 psig**, a **high-pressure protection** is required.

Risk of injury due to unauthorised unit modifications, incorrect installation or damaged components. The operating licence expires in these cases. **Operation is only permitted with original components.** Only operate the flow sensor when it is completely assembled. Do not operate a damaged sensor, and prevent further use of the sensor until it is repaired. The sensor must be checked and maintained regularly by trained and qualified individuals. Device modifications are not permitted and release the manufacturer from any warranty and liability.

Dirt particles in the compressed air will cause measurement errors. Dirt particles and liquids can contaminate the measuring tips of the sensor and lead to malfunction or failure. The system operator must ensure the prescribed purity of the fluids approved for the application as well as appropriate cleaning and maintenance intervals. The manufacturer provides no warranty and accepts no liability of any kind with regard to misuse.

Explosion hazard in potentially Ex-protective zones due to ignition of explosives when sparks are generated.

Please use the VD 550 Ex sensor in explosion-protected areas.

Password protection for settings menu: Password protection is provided to protect against unauthorised entries/settings of the system parameters. For setting the password → chapter 11.3.5.1.

Danger of burns from hot sensor shaft. Hot air/gas/gas mixtures in the pipe can warm up or heat the sensor shaft of the flow sensor. Only touch the sensor shaft when it has cooled down. If applicable, use protective gloves.

Danger to life from escaping compressed air if it is directed at people, especially at high pressure. Shut off the compressed air line at the installation site with a G ½" or NPT ½" ball valve already installed. If a ball valve has not yet been installed, depressurise the system and check the depressurised state. Install G ½" or NPT ½" ball valve (depending on version) according to the specification. Ensure proper installation.

Danger if the applicable regulations for electrical installations are not observed. For electrical installation, observe the applicable regulations, e.g. DIN EN 50110-1. In Germany observe in particular VDE 0100 in the relevant parts. Observe local regulations. Before working on the electrical installation, switch off all supply circuits, switch off the mains fuse and secure against being switched on again. Ensure voltage-free status. Operate the flow sensor only with permissible connection cables for the mains supply and bus connection → technical data. Establish the electrical connection according to the wiring diagram (→ chapter 10).

Exercise due care when handling packaging materials.

Comply with applicable safety and accident prevention regulations. Keep packaging material out of reach of children (choking hazard if small parts are swallowed).

Seals/sealants: As a suitable sealant for the screw connections of the ball valve or flow sensor, sealing rings made of copper or aluminium, elastomer sealing rings with metal backing, sealing tape/sealing cord or other equivalent sealants that meet the demands of the required, necessary compressed air quality can be used.

8.2 Environmental protection

The flow sensor and also the packaging contain recyclable materials that must not be disposed of in the residual waste. At the end of use, dispose of the packaging materials and flow sensor in an environmentally friendly manner in accordance with the regulations in your country.

The operating materials and auxiliary materials consumed and any parts that are replaced during operation of the flow sensor must be disposed of in accordance with environmental protection regulations.

Germany: Disposal code according to the Waste Catalogue Ordinance (AVV) **16 02 14**, electrical and electronic devices and their components

9 Technical data

9.1 Technical data and ambient conditions

Measured variables	Flow rate, total consumption, pressure, temperature, speed
Sensor principle	Differential pressure
Measuring range	Up to 600 m/s* Compressed air 0.04 ... 500 mBar Differential pressure for gases
Accuracy	±1.5 % of m
Repeatability:	0.25% of the measured value with correct installation
Accuracy data:	related to. Ambient temperature :22°C +/-2°C, System pressure:: 6 bar
Media temperature (measurment tip)	-30 ...180 °C / -40 ... 356 °F (Standard) -30 ...85 °C / -40 ... 185 °F (EX-Version)
Ambient temperature	-20 ... 70 °C / -4 ... 140 °F
Storage temperature	-40 ... 80 °C / -40 ... 176 °F
Pollution level	2
Relative humidity Transportation, storage Operation	99.9% rH, non-condensing (installation after functioning water separator) ISO 8573-1:2010 Water class 5 (7 °Ctd)
Operating pressure	Up to 100 bar (1450 psig) Provide additional high pressure protection for pressures >16 bar (>232 psig)
Compressed air requirements min.	ISO 8573-1 (particle moisture oil) 5-6-4
Installation length / shaft lengths	220 mm (standard length), 400 mm
Mounting thread	G ½" or NPT ½"
Power supply	18 to 36 VDC via SELV supply, 5 W or Power over Ethernet in accordance with IEEE 802.3af, class 2 (3.84 ... 6.49 W). Fuse protection in supply unit T2.5L 125V If used at an altitude of over 2000 m, the power supply unit must also be approved for this altitude
Power consumption	Max. 6.5W
Signalausgang	Modbus-RTU (RS-485) Optional: Modbus-TCP Ethernet 1x AO 4...20 mA RL<500Ohm Optional 2x 4.20mA galvanically isolated MBus

	(flow rate, temperature or speed) Alarm output ; 48Vdc/0.5A (NC-normally closed) Pulse output: 48Vdc/0.5A
Protection class	IP 67
Display:	2" TFT Color-Display (320 x 240)
Material	Die-cast aluminum housing Sensor tube stainless steel 1.4404

* based on ISO 1217 with 1000 mbar / 14.50 psi at 20 °C / 68 °F

** v. M. = from measured value | v. E. = from final value

9.2 Signal circuits

9.2.1 Modbus

- According to standard EIA/TIA-485

9.2.2 Current output

9.2.2.1 Active

- Galvanically isolated
- 4 ... 20 mA
- $R_L < 500 \text{ Ohm}$

9.2.2.2 Passive

- Galvanically isolated
- 4 ... 20 mA
- $R_L < 500 \text{ Ohm}$
- $V_{in} 12\text{-}36\text{Vdc}$


9.2.3 Impulse

- Galvanically isolated / potential-free switching contact
- Passive: 48Vdc , 500 mA
- Max. Pulse output frequency 50Hz

9.2.4 Alarm

- Galvanically isolated
- Max. 48Vdc, 500mA

9.3 Dimensions VD 550



9.4 Measuring ranges flow rate VD 550

The VD 550 volumetric flow sensor is available in 3 different versions:

- High-speed version up to max. flow velocity of 224 m/s
- Ultra High Speed version up to max. flow velocity of 600 m/s
- Version A3 0.04 ... 500 mBar differential pressure (gases)

The probes are **preset** for an internal pipe diameter of **53.1 mm**.

	Measuring range	Analog output Scaling
• High speed version	0...1450 m ³ /h	4mA = 0 m ³ /h, 20mA = 1450 m ³ /h
• Ultra Speed version	0...3884 m ³ /h	4mA = 0 m ³ /h, 20mA = 3884 m ³ /h

If the sensors are used in **other** pipe diameters, the corresponding inside diameter must first be entered for versions with a display.

The corresponding measuring range end values can be found in chapter 7.4.

Example:

Pipe 1", inner diameter 25mm

	Measuring range	Analog output Scaling
• High speed version	0...295 m ³ /h	4mA = 0 m ³ /h, 20mA = 295 m ³ /h
• Ultra Speed version	0...790 m ³ /h	4mA = 0 m ³ /h, 20mA = 790 m ³ /h

To change the inner pipe diameter and adjust the scaling of the 4... 20mA analog output, see chapter 11 "Operation"

9.4.1 Measuring range end values „224 m/s“

Measuring tube Inner diameter		Volume flow (measuring range end value in Nm³/h)		Max
Închl	mm	Air 2)	Air 3)	m/s
3/4"	21,7	215	198	224,0
1"	25,0	295	272	224,0
	26,0	321	296	224,0
	27,3	357	328	224,0
	28,5	391	360	224,0
	30,0	437	402	224,0
1 1/4"	32,8	529	487	224,0
	36,0	644	592	224,0
	36,3	655	603	224,0
1 1/2"	39,3	775	713	224,0
	40,0	804	740	224,0
	41,9	886	816	224,0
	43,1	941	866	224,0
	45,8	1068	983	224,0
2"	50,0	1283	1180	224,0
	51,2	1346	1239	224,0
	53,1	1450	1335	224,0
	54,5	1529	1408	224,0
	57,5	1713	1577	224,0
	60,0	1870	1721	224,0
	64,2	2148	1977	224,0
2 1/2"	65,0	2205	2029	224,0
	70,3	2589	2383	224,0
	71,1	2648	2437	224,0
	76,1	3041	2799	224,0

Measuring tube Inner diameter		Volume flow (measuring range end value in Nm³/h)		Max
Inchl	mm	Airt 2)	Air 3)	m/s
3"	80,0	3364	3097	224,0
	82,5	3582	3297	224,0
	84,9	3794	3492	224,0
	90,0	4268	3929	224,0
4"	100,0	5276	4856	224,0
	107,1	6059	5577	224,0
	110,0	6391	5883	224,0
5"	125,0	8263	7606	224,0
	133,7	9453	8701	224,0
6"	150,0	11913	10965	224,0
	159,3	13436	12367	224,0
	182,5	17656	16251	224,0
	190,0	19137	17614	224,0
8"	200,0	21230	19540	224,0
	206,5	22632	20831	224,0
10"	250,0	33211	30568	224,0
	260,4	36075	33204	224,0
12"	300,0	47881	44070	224,0
	309,7	51027	46966	224,0
	339,6	61356	56473	224,0
	400,0	85122	78347	224,0
	500,0	133003	122417	224,0
	600,0	191524	176281	224,0
	700,0	260685	239938	224,0
	800,0	340487	313388	224,0
	900,0	430929	396632	224,0
	1000,0	532011	489669	224,0

²⁾ Based on DIN 1945 / ISO 1217 (20°C, 1000mbar) and compressed air.

³⁾ Setting to DIN 1343: 0°C, 1013.25 mbar

9.4.2 Measuring range end values „600 m/s“

Measuring tube Inner diameter		Volume flow (measuring range end value in Nm³/h)		Max
Zoll	mm	Airt ²⁾	Air ³⁾	m/s
3/4"	21,7	578	531	600,0
1"	25,0	791	727	600,0
	26,0	860	791	600,0
	27,3	956	879	600,0
	28,5	1048	964	600,0
	30,0	1171	1077	600,0
1 1/4"	32,8	1416	1302	600,0
	36,0	1724	1585	600,0
	36,3	1755	1614	600,0
1 1/2"	39,3	2075	1908	600,0
	40,0	2152	1979	600,0
	41,9	2374	2183	600,0
	43,1	2521	2318	600,0
	45,8	2861	2631	600,0
2"	50,0	3435	3158	600,0
	51,2	3607	3316	600,0
	53,1	3884	3571	600,0
	54,5	4097	3767	600,0
	57,5	4588	4218	600,0
	60,0	5008	4605	600,0
	64,2	5755	5291	600,0
2 1/2"	65,0	5906	5430	600,0
	70,3	6934	6376	600,0
	71,1	7092	6521	600,0
	76,1	8145	7489	600,0

Measuring tube Inner diameter		Volume flow (measuring range end value in Nm³/h)		Max
Zoll	mm	Air ²⁾	Air ³⁾	m/s
3"	80,0	9012	8286	600,0
	82,5	9595	8822	600,0
	84,9	10162	9344	600,0
	90,0	11433	10512	600,0
4"	100,0	14132	12994	600,0
	107,1	16229	14922	600,0
	110,0	17120	15741	600,0
5"	125,0	22134	20351	600,0
	133,7	25321	23282	600,0
6"	150,0	31910	29340	600,0
	159,3	35990	33091	600,0
	182,5	47293	43484	600,0
	190,0	51260	47131	600,0
8"	200,0	56865	52285	600,0
	206,5	60621	55738	600,0
10"	250,0	88958	81793	600,0
	260,4	96628	88845	600,0
12"	300,0	128252	117922	600,0
	309,7	136680	125690	600,0
	339,6	164345	115130	600,0
	400,0	228004	209670	600,0
	500,0	356256	327610	600,0
	600,0	513009	471758	600,0
	700,0	698262	642116	600,0
	800,0	912017	838682	600,0
	900,0	1154271	1061458	600,0
	1000,0	1425026	1310441	600,0

²⁾ Bezogen auf DIN 1945 / ISO 1217 (20°C, 1000mbar) und Druckluft.

³⁾ Einstellung auf DIN 1343: 0°C, 1013,25 mbar

10 Installation / Assembly

10.1 Placement of the flow sensor, pipelines

- To ensure precise measurement results, the VD 550 must be properly installed in the pipe.
- Only use correctly dimensioned seals suitable for the flow medium.
- Avoid diameter jumps in the pipe (inlet section) at the joints (max. 1 mm). For more information → ISO 14511:2019-01.
- Observe specified flow direction □ sensor shaft with scaling and flow direction arrows on the sensor head.
- After the installation work, ensure that the pipe is clean.
- Condensation or water drops on the sensor element lead to faulty measurement results. For this reason, do not install the flow sensor with the measuring tips pointing upwards or in downpipes.

10.2 Necessary inlet and outlet sections



NOTE

▶ The principle of thermal mass flow measurement applied here is sensitive to flow disturbances and turbulence. To maintain the accuracies specified in the data sheets, the sensor must be inserted centrally in a straight piece of pipe at a point with undisturbed flow.

Undisturbed flow is achieved when a sufficiently long section upstream of the sensor (inlet section) and downstream of the sensor (outlet section) that is absolutely straight and without any points of disturbance such as edges, seams, bends and so on is provided.

When placing the sensor, take note of the necessary inlet and outlet sections. Only on this basis are precise measurement results possible.



NOTE


▶ The following figures show the respective required minimum lengths of the calming sections. If the sections are shortened, increased deviations of the measurement results need to be calculated → Avoid shortened sections.

10.3 Inlet / outlet sections

Required inlet and outlet sections in the measuring pipe range

inlet and outlet sections: D = inner pipe diameter

Flow obstacle in front of the measuring section	Minimum length Inlet section (L1)	Minimum length Outlet section (L2)
Low curvature (bend < 90°)	12 x D	5 x D
Reduction (pipe narrows to the measuring section)	15 x D	5 x D
Extension (pipe extends to the measuring section)	15 x D	5 x D
90° bend or T-piece	15 x D	5 x D
Two bends at 90° in one plane	20 x D	5 x D
Two bends at 90° Three-dimensional change of direction	35 x D	5 x D
Shut-off valve	45 x D	5 x D



The required minimum values are specified in each case. If the specified settling distances cannot be adhered to, increased to considerable deviations in the measurement results must be expected

10.4 Installation VD 550

The sensor is installed via a ½" ball valve.

If no suitable measuring point with ball valve ½" is available, there are the following options for setting up a measuring point



When using the consumption sensor in systems with operating pressure >16 bar, the use of a high-pressure safety device is required for safety reasons.

10.4.1 ½" welded nipple with ball valve



Important:

Ensure that the system is shut down, i.e. depressurized.

Note for installation with ball valve:

Ball valve R ½", DN 15

Passage ball valve minimum Ø15 mm

10.4.2 Spot drilling collar with ball valve



In case the system could not be shut down, means to be set depressurized, there could be used the CS spot drilling collar (Order-No. 0530 1108) and drilling jig (Order-No. 0530 1108) to drill through the ball valve.


10.5 Installation of the sensor

10.5.1 Mounting the VD 550 in the ball valve

10.5.2 Installation instructions

- The sensor must be screwed into the ball valve in a pressure-tight manner (tightening torque 25...30 Nm).
- Before fixing the sensor, set the insertion depth and align the angular position. Observe the safety instructions.
- If necessary, turn the display head of the control unit (→ Chapter 8.7) or rotate the display (if the reading direction is upside down, rotate the LCD > Chapter 11 "Operation").
- Ensure that the retaining ring attached to the sensor head is undamaged and correctly fitted.
- After aligning the sensor, tighten the clamping sleeve with a torque of 25 ... 30 Nm (SW 17).
- Correct zero point adjustment

Calculation mounting depth::



Flow direction setting





WARNING

Components under high pressure! Risk of injury if the flow sensor is not installed in a pressure-tight manner.

▶ After installation, be sure to check and ensure the pressure tightness of the connection. Do not work directly over the sensor, but next to it to minimise possible hazards.





Note

▶ Do not change the orientation of the sensor when tightening the connecting nut] and clamping sleeve, If this still happens, check the setting depth and alignment again and correct them if necessary..

1. Close the ball valve.
2. Push the connecting nut completely over the measuring tips . Do not damage the safety ring when doing so.
3. Apply sealing material to the thread of the G ½" or NPT ½" screw connection of the connecting nut. Only use suitable sealing material that matches the flow medium.
4. Screw the flow sensor with the G ½" or NPT ½" screw connection of the connecting nut into the ball valve (size 32) and tighten with a tightening torque of 25...30 Nm. The sensor shaft is not yet fixed in place. Do not damage the measuring tips of the sensor.

Sensor Adjustment

To ensure correct measured values, a maximum angle deviation of $\pm 2^\circ$ is permitted.



Reference point = tip of the alignment key

5. **Set the measuring tip of the sensor to the centre of the pipe and align them.**

To do this, insert the sensor shaft in the direction of the pipe centre according to the depth scale (setting value = X + Y) and align with an **angular deviation of no more than $\pm 2^\circ$** . Observe the flow direction according to the directional arrows.



NOTE

▶ Use the alignment key supplied for correct directional positioning. In relation to the ideal position, the angular deviation should not exceed $\pm 2^\circ$. If the alignment is imprecise, measurement inaccuracies are to be expected.


6. Tighten the sensor shaft with the clamping sleeve with a tightening torque of 25...30 Nm..

10.6 Installation angle for installation locations with potential water incidence



Notes

- ▶ **Faulty measurement results with impermissible installation position. Condensation or water drops on the sensor element lead to faulty measurement results. No condensation is allowed on the sensor measuring tips.**
- Avoid installation locations that could potentially accumulate water.
 - Do **not** install the flow sensor with the measuring tips pointing upwards, since any condensate/water that forms can no longer flow off.
 - Do **not** install the flow sensor in a downpipe.
 - Installation in a riser is possible in general.



1. We recommend installing the flow sensor at an angle of at least 15 degrees.
In installation positions $>15^\circ$, any condensate or water can drip off properly.
2. Carrying out zero point adjustment see chapter 11.2 and 13.3.1.5

10.7 Alignment of housing / display

The VD 550 sensor housing can be rotated in both directions, max. 345°. To do this, the locking screw in must be loosened. The housing can then be rotated to the desired position; over-rotation is prevented by the internal stop.

Then tighten the locking screw again.



11 Commissioning



WARNING

Danger from pressurised components.

- ▶ Ensure sufficient and safe compressed air quality with a compressed air system. If operating pressures are too low over an extended period of time, the flow velocity in the pipe increases sharply. This can lead to major impairments in the compressed air preparation. Install a compressed air system to prevent this.
- ▶ When commissioning for the first time, ensure that the operating pressure is adapted to the consumer network.

11.1 Sensor switch on

1. Ensure that the flow sensor is correctly connected.
2. After the power supply is applied (initial start or after a reset), the reset), the VD 570 flow sensor switches on and performs a device initialization for approx.. 2...3 seconds.

11.2 Zero point adjustments

The VD 550 flow sensor measures the flow velocity (differential pressure principle) in the middle of the pipe.



To achieve the required measuring accuracy, the sensor must first be zeroed at the start of measurement.

1. Loosen the clamping sleeve
2. Ensure that there is no flow by pulling the sensor out up to the stopper.
3. Pressurize the sensor with system pressure, open the ball valve if necessary..
4. To ensure that there is no flow during zero point calibration, we recommend closing the ball valve again
5. It is essential that the sensor is aligned parallel to the pipe using the alignment key supplied before zero point calibration..
6. After correct alignment wait 20 seconds.
7. Then start the zero point calibration on the sensor → chapter Operation
8. after zero-point calibration, the sensor tip must be reinstalled in the pipe without changing the alignment. → chapter 10.5



RECOMMENDATION

- ▶ Carry out zero point adjustment every 180 days to ensure precise measurement results.

12 Connection diagram

12.1 Cable glands - clamping ranges

For ensuring the tightness and strain relief, connector cables with the following diameters must be used.

VD 550 Standard clamping range : Ø 5- 9mm

VD 550 Ex clamping range : Ø5-10mm


Tightening torque for cable gland cap nut: 9 Nm

12.2 Wire connection

12.2.1 General:

- Wiring to be done in strainless state only.
- Length of cable skinning to be minimized
- Not used cable entries must be closed with end caps
- Use of shielded cables
- Use of cables with cross section of $\geq 0.25\text{mm}^2$


12.2.2 Power supply



12.2.3 Modbus RTU:

If the sensor placed at the end of the Modbus system a termination is required.

Therefore, the enclosed 120R resistor is to be connected at Pin 1 and Pin 3 of connector „X2“




12.2.4 Modbus TCP (Ethernet) Optional PoE

M12 x-coded

Data LINES: 1,2 und 3,4


PoE LINES: 5,6 und 7,8




Connection cable: Cat 6.

*PoE: Power over Ethernet


12.2.5 Pulse Output



12.2.6 Option MBus



12.2.7 Option 2x 4..20mA (galv. getrennt)



Connector	Pin	Signal Deskription
X1 Power supply	1	VB - (GND)
	2	VB+
X2 Modbus	1	Modbus (B)
	2	Modbus shield
	3	Modbus (A)
X3 current output	1	I- Active
	2	I+ Active
X4 Direction / Pulse	1	Pulse / Alarm *
	2	Pulse / Alarm *
	3	Direction input
	4	GND
X5 Current output 1	1	I- Active**
	2	I+ Active **
X6 Current output 2	1	I- Active **
	2	I+ Active **
K1 Mbus	1	Mbus
	2	Mbus


* Outputs are galvanically isolated.

** The Current outputs, X5 and X6, are optional.(Active and passive version available).

13 Operation VD 550

Note: Only for version with display

The VD 550 is operated using 2 optical buttons, which are operated directly via / through the glass cover. This means that the VD 550 can be operated from the outside without opening the cover.



The individual menu items are selected using the ">" button and confirmed by pressing the **"OK"** button

Information or changes can be made in all fields with a white background; the selection for input is indicated by a yellow background color.

Words in *green* mainly refer to the figure(s) in the chapter section. But also important menu paths or menu items that are related to it are marked in *green letters*.

The menu navigation is generally in *green font*!

The table of contents and the chapter references in *blue font* contain links to the respective chapter headings.


13.1 Main menu (Home)

13.1.1 Initialization




After switching on the VD 550, initialization takes place, see right, followed by the main menu..

13.2 Main menu after switching on



Switching to pages 2-4 or back by pressing key „>“



AV-Time (Period for average value calculation) could be changed under *Sensor Setup.-Advanced-AV-Time*

13.3 Settings


The settings menu could be accessed by pressing the key „OK“.

But the access to the *settings menu* is password protected.



Factory settings for password at the time of delivery: 0000 (4 times zero).

If required the password could be changed at *Setup–User setup-Password*.



Selection of a menu item or to change a value is done with the key „>“, a final move to the chosen menu item or takeover of the value change needs the confirmation by pressing the key „OK“

13.3.1 Sensor Settings

Setup → Sensor

For changes, first select the menu item with key „>“ and then confirm it with **“OK”**.

13.3.1.1 Input / change tube diameter

Settings → Sensor → Diameter

In order to change, e.g. the unit, first select by pressing key „>“ the field **“Units”** and then key **“OK”**.

Select with the key „>“ the correct unit and then confirm selection by pressing 2x **„OK”**.



Entering / changing the diameter via button „>“, select the respective position and activate the position with the **“OK”** button.

By pressing „>“ the position value is incremented by 1. Complete with **“OK”** and activate next number position.

Confirming entry by pressing **„OK”**.

13.3.1.2 Input / change consumption counter

Settings → **Sensor** → **Total Counter** → **Unit button**



In order to change, e.g. the unit, first select by pressing key „>“ the button **“Unit”** and then key **“OK”**.

Select with the key „>“ the correct unit and then confirm selection by pressing 2x **„OK”**.

Entering / changing the consumption counter via button „>“, select the respective position and activate the position with the **“OK”** button.

By pressing „>“ the position value is incremented by 1. Complete with **“OK”** and activate next number position.


Confirm entry by pressing **„OK”**.

Important!

When the counter reach 100000000 m³ the counter will be reset to zero.

13.3.1.3 Definition of the units for flow, velocity, temperature and pressure

Settings → **Sensor** → **Units**







To make changes to the unit for the respective measurement value, first select by pressing „>“ the field of the „measurement value“ and activate „it with **„OK”**.

Selection of the new unit with „>“

In case the quantity of units selectable are not presentable on one page, please move to next page by pressing **„<<”**.

Confirm selection by pressing 2x **„OK”**.

Procedure for all 4 measurement-variables is analogous.



13.3.1.4 Definition of the reference conditions

Here can be defined the desired measured media reference conditions for pressure and temperature and times for the filter and averaging.

Note


- Factory pre-setting for reference temperature and reference pressure are 20 °C, 1000 hPa
- All volume flow values (m³/h) and consumption values indicated in the display are related to 20 °C and 1000 hPa (according to ISO 1217 intake condition)
- Alternatively 0 °C and 1013 hPa (=standard cubic meter) can also be entered as a reference.
- **Do not enter the operation pressure or the operation temperature under reference conditions!**

Settings → Sensor → Advanced → Ref. settings → Ref. pressure



To make changes, first select a menu with button „>“ and confirm selection by pressing „OK“.

Settings → Sensor → Advanced → Ref. settings → Ref.Pref




In order to change, e.g. the unit, first select by pressing key „>“ the field **“Units”** and then key **“OK”**.

Select with the key „>“ the correct unit and then confirm selection by pressing 2x **„OK”**.

Input / change of the value by selecting the respective position with button „>“ and entering by pressing button **„OK”**.

Settings → Sensor → Advanced → Ref. settings → Ref.Temp



By pressing „>“ the position value is incremented by 1. Complete with **“OK”** and activate next number position.

Procedure for changing the reference temperature is the same.

13.3.1.5 Setting of Zeropoint and Low-flow cut off

Settings → Sensor → ZP Adjust

Zero Point Setup

DeltaPressure ----- hpa

ZeroPnt 0 days remaining

CutOff ----- m³/h

Reset Back

To make changes, first select a menu with button „>“ and confirm selection by pressing „OK“.

Settings → Sensor → ZP Adjust → ZeroPnt

Zero Point Setup

DeltaPressure ----- hpa

ZeroPnt 0 days remaining

CutOff ----- m³/h

Reset Back

Zero Point Setup

DeltaPressure ----- hpa

ZeroPnt 180 days remaining

CutOff ----- m³/h

Reset Back

If the sensor shows the message „CalZeroPnt“ in the display, a zero point calibration should be carried out, see also chapter 9 and 11 "Zero point calibration"..



For zero point calibration, pull the sensor out completely as far as it will go

Select the „ZeroPnt“ button and start the calibration with „OK“.

Settings → Sensor → ZP Adjust → CutOff

LowFlow Cut off

0.00 m³/h

CLR Back

With the low-flow cut off activated, the flow below the defined "LowFlow Cut off" value will be displayed as 0 m³/h and not added to the consumption counter.

For an input / change of the value select with the button „>“ the respective number position and activate it with „OK“.

By pressing „>“ the position value is incremented by 1. Confirm the input with „OK“ and activate next number position.

Leave menu with button „Back“

Settings → Sensor → ZP Adjust t → Reset

Zero Point Setup

DeltaPressure ----- hpa

ZeroPnt 180 days remaining

CutOff ----- m³/h

Reset Back

By selection of „Reset“ all settings for „ZeroPnt“ and „CutOff“ are reset.

Menu item to be select with button „>“ and confirm the reset with „OK“.

Leave menu with button „Back“

13.3.2 Modbus RTU

13.3.2.1 Setup

The Flow sensors VD 550 comes with a Modbus RTU Interface.
Before commissioning the sensor the communication parameters

- Modbus ID, Baud rate, Parity und Stop bit

must be set in order to ensure the communication with the Modbus master.

Settings → Modbus RTU

For changes, e.g. the sensor ID, first select by pressing key „>“ the field **“ID”** and then key **“OK”**.

Select the desired position by pressing the **“>”** and select with **“OK”** button.

Change values by pressing the **“>”** values takeover by pressing **“OK”**.

Inputs for baudrate, stopbit and parity is done analogue.

By means of the button "Byte Order" it is possible to change the data format (Word Order). Possible formats are "ABCD" (Big Endian) and "CDAB" (Middle Endian)

Saving the changes by pressing **“Save”**, therefore select it with key **“>”** and then confirm it with **“OK”**.

Reset to the default settings by activating **“Default”**.

Default values out of factory:

Modbus ID:	1
Baud rate:	19200
Stopbit:	1
Parity:	even
Byte Order:	ABCD

Remark: If the sensor placed at the end of the Modbus system, a termination is required. Therefore, the enclosed 120R resistor is to be connected at Pin 1 and Pin 3 of connector „X2“

13.3.3 Modbus TCP (Optional)

13.3.3.1 Setup

The Flow sensors VD 550 comes optional with a Modbus TCP Interface (HW Interface:M12 x 1 X-coded connector).

Device supports with this option the Modbus TCP protocol for communication with SCADA systems. TCP port is set to 502 by default. Port can be changed at the sensor or using PC Service Software

Modbus device address (Unit Identifier) can be set in the range of 1- 247.

Specification and description of the Modbus protocol is free to download on: www.modbus.org.

Supported Modbus commands (functions):

Command	Code	Description
Function Code	3	(Read holding register)
Function code	16	(Write multiple registers)

For more details, please see **VA 5xx Modbus RTU_TCP Installation in it actual version**

Settings → Network

13.3.3.1.1 Network Setup DHCP

Settings → Network → IP Address

Here you can set up and made a connection, with or without **DHCP**, to a computer.

Remark:

With activated **DHCP** the automatic integration of the sensor in an existing network is possible, without a manual configuration.

Storing of settings by pressing **“Save”**

13.3.3.1.2 Network Settings static IP

Settings → Network → IP Address → IP Address

Settings → Network → IP Address → Sub Netz

Settings → Network → IP Address → Gateway

*** IP Address Setup ***

DHCP ☐

IP Address 192.168.172.010

Subnet 255.255.255.000

Gateway 192.168.172.001

Advanced

*** IP Address Setup ***

DHCP ☐

IP Address 192.168.172.010

Subnet 255.255.255.000

Gateway 192.168.172.001

Advanced

IP Setup

1 9 2

CLR

For manual (static) IP, the **"IP Address"**, **"Subnet"** and **"Gateway"** selection keys must be selected and activated with **"OK"**.

The first data field of the selection, in this case the IP address, is then marked (red).

Confirm with **"OK"** the corresponding input menu is opened.

By means of **">"**, the next data field is changed.

Select the desired position with the **">"** key and activate it with the **"OK"** key.

Change the values with the **">"** key, and accept the values with the **"OK"** key.

Procedure for **"Subnet"** and **"Gateway"** is analogous.

Subnet Setup

2 5 5

CLR

Gateway Setup

1 9 2

CLR

*** IP Address Setup ***

DHCP ☐

IP Address 192.168.172.011

Subnet 255.255.255.000

Gateway 192.168.172.001

Advanced

Store the settings by **„Save“**

13.3.3.1.3 Modbus TCP Settings

Settings → Network → IP Address → MB TCP

*** MB TCP ***

ID	5
Port	502
Byte Order	ABCD

Set to Default back

Settings → Network → IP Address → ID

Settings → Network → IP Address → Port

Modbus TCP UI

5

CLR back

Modbus TCP Port

502

CLR zurück

For changes, e.g. the sensor ID, first select by pressing key „>“ the field **“ID”** and then key **“OK”**.

Select the desired position by pressing the **“>”** and select with **“OK”** button.

Change values by pressing the **“>”** values takeover by pressing **“OK”**.

Input for the port is done analogue.

By means of the button **“Byte Format”** it is possible to change the data format (Word Order). Possible formats are **“ABCD”** (Big Endian) and **“CDAB”** (Middle Endian)

Saving the changes by pressing **“Save”**, therefore select it with key **“>”** and then confirm it with **“OK”**.

Reset to the default settings by activating **“Set to Default”**-

13.3.3.2 Modbus Settings (2001...2005)

Modbus Register	Register Adresse	No.of Byte	Data Type	Description	Default Setting	Read Write	Unit /Comment
2001	2000	2	UInt16	Modbus ID	1	R/W	Modbus ID 1...247
2002	2001	2	UInt16	Baudrate	4	R/W	0 = 1200 1 = 2400 2 = 4800 3 = 9600 4 = 19200 5 = 38400
2003	2002	2	UInt16	Parity	1	R/W	0 = none 1 = even 2 = odd
2004	2003	2	UInt16	Number of Stopbits		R/W	0 = 1 Stop Bit 1 = 2 Stop Bit
2005	2004	2	UInt16	Word Order	0xABCD	R/W	0xABCD = Big Endian 0xCDAB = Middle Endian

13.3.3.3 Values Register (1001 ...1500)

Modbus Register	Register Adresse	No.of Byte	Data Type	Description	Default	Read Write	Unit /Comment
1101	1100	4	Float	Flow in m³/h		R	
1109	1108	4	Float	Flow in Nm³/h		R	
1117	1116	4	Float	Flow in m³/min		R	
1125	1124	4	Float	Flow in Nm³/min		R	
1133	1132	4	Float	Flow in ltr/h		R	
1141	1140	4	Float	Flow in Nltr/h		R	
1149	1148	4	Float	Flow in ltr/min		R	
1157	1156	4	Float	Flow in Nltr/min		R	
1165	1164	4	Float	Flow in ltr/s		R	
1173	1172	4	Float	Flow in Nltr/s		R	
1181	1180	4	Float	Flow in cfm		R	
1189	1188	4	Float	Flow in Ncfm		R	
1197	1196	4	Float	Flow in kg/h		R	
1205	1204	4	Float	Flow in kg/min		R	
1213	1212	4	Float	Flow in kg/s		R	
1221	1220	4	Float	Flow in kW		R	

Modbus Register	Register Adresse	No. of Byte	Data Type	Description	Default	Read Write	Unit /Comment
1269	1268	4	UInt32	Consumption m³ before comma	x	R	
1275	1274	4	UInt32	Consumption Nm³ before comma	x	R	
1281	1280	4	UInt32	Consumption ltr before comma	x	R	
1287	1286	4	UInt32	Consumption Nltr before comma	x	R	
1293	1292	4	UInt32	Consumption cf before comma	x	R	
1299	1298	4	UInt32	Consumption Ncf before comma	x	R	
1305	1304	4	UInt32	Consumption kg before comma	x	R	
1311	1310	4	UInt32	Consumption kWh before comma	x	R	
1347	1346	4	Float	Velocity m/s			
1355	1354	4	Float	Velocity Nm/s			
1363	1362	4	Float	Velocity Ft/min			
1371	1370	4	Float	Velocity NFt/min			
1419	1418	4	Float	GasTemp °C			
1427	1426	4	Float	GasTemp °F			

Remark:

- For DS400 / DS 500 / Handheld devices - Modbus Sensor Datatype „Data Type R4-32“ match with „Data Type Float“
- For more additional Modbus values please refer to VA5xx_Modbus_RTU_TCP Installation in its actual version

13.3.4 Pulse /Alarm

Setup → Sensor → Pulse/ Alarm

Pulse/Alarm	
Relay Mode:	Alarm
Unit	°C
Value	20.00
Hyst.	5.00
Exceed	OK Cancel

Pulse/Alarm	
Relay Mode:	Alarm
Unit	°C
Value	20.00
Hyst.	5.00
Exceed	OK Cancel

Pulse/Alarm	
Relay Mode:	Pulse
Unit	m³
Value	0.10
Polarity	pos.
Pulse/s at Max. Flow:	1610612736 Back

The galvanically isolated output can be defined as pulse- or alarm output. Selection of field „**Relay Mode**“ with key „>“ and change modus by pressing key „OK“.

For alarm output following units could be chosen: kg/min, cfm, ltr/s, m³/h, m/s, °F, °C and kg/s.


„**Value**“ defines the Alarm value, „**Hyst.**“ defines the desired hysteresis and with „**Hi-Lim**“ or „**Lo-Lim**“ the alarm settings when the alarm is activated

Hi-Lim: Value over limit

Lo-Lim: Value under limit

For the pulse output following units could be chosen: kg, cf, ltr and m³. The pulse value definition to be done in menu „**Value**“. Lowest value is depending on max. flow of sensor and the max frequency of pulse output of 50Hz.

With „**Polarity**“ the switching state could be defined. Pos. = 0 → 1 neg. 1 → 0



13.3.4.1 Pulse output

The maximum frequency for pulse output is 50 pulses per second (50Hz).

The Pulse output is delayed by 1 second.

Pulse value	[m³ /h]	[m³ /min]	[l/min]
0.1 ltr / Pulse	18	0,3	300
1ltr / Pulse	180	3	3000
0.1m³ / Pulse	18000	300	300000
1 m³ / Pulse	180000	3000	3000000

Table 1 Maximum flow for pulse output

Entering pulse values that are not allow a presentation to the full scale value, are not allowed. Entries are discarded and error message displayed.

13.3.5 User Settings

13.3.5.1 Password

Settings → User → Password



To make changes, first select a menu with button „>“ and confirm selection by pressing „OK“.

It is possible to define a password. The required password length is 4 digits. Please select with button „>“ a figure and confirm it with „OK“. Repeat this 4 times.


With „<“ the last figure could be deleted. Password input have to be inserted twice.

Confirmation of input/password by pressing „OK“.

Factory settings for password at the time of delivery: 0000 (4 times zero).

13.3.5.2 Language

Settings → User → Language




Currently 4 languages have been implemented and could be selected with button „>“.

Change of language by confirming with „OK“. Leaving the menu with button „back“.

13.3.5.3 Display / Touch

Settings → User → Display / Touch



With the button „-“ and with button „+“ it is possible to adjust the backlight / display brightness. The actual / adjusted backlight brightness is showed in the graph „**Backlight.**“

By activation **“Dimming after”** and entering a time a display dimming could be set.


With **„Rotate Screen“** the display information could be rotated by 180°.

By activation of **„Key Lock“** the operation of the sensor locked.

Unlocking the keyboard is only possible by restarting the sensor and calling the operating menu within the first 10s. To do this, use the **“OK”** button to enter the operating menu during this period

13.3.6 Advanced

Settings → Advanced



By pressing **„Factory Reset“** the sensor is set back to the factory settings.

13.3.7 4 -20mA

Settings → 4-20mA

4 - 20mA Settings	
Channel 1	Flow
Channel 2	
Channel 3	
Error Current	22mA
Back	

To make changes, first select a menu with button „>“ and confirm selection by pressing „OK“.

Settings → 4-20mA → Channel 1

4 - 20mA Channel 1	
Flow	Unit
AutoRange	on
Scale 4mA	0,000 m³/h
Scale 20mA	100,0 m³/h
→ 0.0 m/s 100.0 m³/h	Back

UnitFlow	
lm³/h	
Nm³/min	m³/min
Nm³/h	m³/h
Nltr/h	ltr/h
Nm³/s	m³/s
<<	OK
Cancel	

4 - 20mA Channel 1	
Flow	Unit
AutoRange	on
Scale 4mA	0,000 m³/h
Scale 20mA	100,0 m³/h
→ 0.0 m/s 100.0 m³/h	Save
Cancel	

The 4-20 mA Analogue output of the Sensor VD 550 can be individually adjusted.

It is possible to assign following values „Temperature“, „Velocity“ und „Flow“ to the channel CH 1.

To make changes, first select the value item with button „>“.and confirm Moving between the different measurements values or to deactivate the 4-20mA with setting to „unused“ by pressing „OK“.

To the selected measurement value a corresponding / appropriate unit needs to be defined. Select „Unit“ with „>“ and open menu with „OK“. Select required unit with „>“ and take over by pressing „OK“.

Here e.g. for the measurement value Flow, procedure for the other measurements values is analog.

For saving the changes done press button „Save“ to discard the changes press button „Cancel“.

Leaving the menu with „Back“.

Settings → 4-20mA → Channel 1 → AutoRange

Flow	Unit
AutoRange	off
Scale 4mA	0,000 m³/h
Scale 20mA	100,0 m³/h

→ | 0.0 m/s
100.0 m³/h

Save Cancel

4mA Scale Low

0.00 m³/h

CLR Back

20mA Scale High

0.00 m³/h

CLR Back

The scaling of the 4-20mA channel can be done automatically "Auto Range = on" or manual "AutoRange = off" .

With button „>“ select the menu item „AutoRange“ select with „OK“ the desired scaling method. (Automatically or manually)

In case of **AutoRange = off** with „Scale 4mA“ und „Scale 20mA“ the scale ranges needs to be defined.

Select with button „>“ the item „Scale 4mA“ or „Scale 20mA“ and confirm with „OK“ .

Input of the scaling values will be analogous as described before for value settings.

Using „CLR“ clears up the complete settings at once.

For „Auto on“, the max. scaling is calculated based on the inner tube diameter, max. measurement range and the reference conditions settings.

Take over of the inputs with „Save“ and leaving the menu with „Back“.

Settings → 4-20mA → Error Current

*** 4 - 20mA Settings ***

Channel 1 Flow

Channel 2 unused

Error Current 22mA

Back

This determines what is output in case of an error at the analog output.

- 2 mA Sensor error / System error
- 22 mA Sensor error / System error
- None Output according Namur (3.8mA – 20.5 mA)
 < 4mA to 3.8 mA Measuring range under range
 >20mA to 20.5 mA Measuring range exceeding

To make changes first select a menu item "Current Error" with button „>“ and then select by pressing the „OK“ the desired mode

For saving the changes done press button „Save“ to discard the changes press button „Cancel“.

Leaving the menu with „Back“.

Bemerkung:

Voreinstellung VD 550 für Analogausgang ist

Voreinstellung VD 550 mit Optionskarte Analogausgang

Max. Durchfluss siehe Etikett am Sensor

Kanal 1: 0...max. Durchfluss [m³/h]

Kanal 1: 0...max. Durchfluss [m³/h]

Kanal 2: -20°C ... 100°C]

13.3.8 VD 550 Info

Setup → Sensor Setup → Info

*** Info ***

Production Data
Serial No.: 1234567890
Cal. Date: 10.01.2013 [Details](#)

Sensor Data
Sensor Type: IST 1.8
Max Speed: 92,7 m/s 600m³/h
Max Temp: 100.0 °C

Live Data
Run Time: 2d 21h 23m 12s
Vin: 23,8V Temp: 35,8

[Options](#) [Back](#)

*** Kalibrier Details ***

Kalibrier Bedingungen

Ref. Druck	1000.00mbar
Ref. Temp	20.0°C
Durchmesser	53.1 mm
Druck	6000.00mbar
Temperatur	24.0°C
Ausführung	Standard

[zurück](#)

Here you get a brief description of the sensor data incl. the calibration data.

Under **Details**, you are able to see in addition the calibration conditions.

13.4 MBus

13.4.1 Change of communication settings

The communication settings Primary-address and baud rate could be changed directly at the sensor, in case sensor has a display, or with the PC Service software (Order-No. 0554 2007).

Settings → M-Bus

Settings	
Sensor	4 - 20mA
Modbus RTU	M-Bus
Pulse/Alarm	
User	Info
Advanced	Back

Settings → M-Bus → Adr

Possible inputs are values from 1-247 (Default setting = 1)

M-Bus

Adr: 1 Baudrate: 2400

ID: 123456

☐ Einheiten als Text

zurück

Primary Address

1

def. **Back**

With „>“ select the button „Adr“ and confirm it with „OK“.

Select the desired position by pressing the button „△“ and select it with „OK“ button.

Change values by pressing „>“ with step of 1, taking the value by confirming with „OK“.

Move to next position with „>“

Using „CLR“ clears up the complete settings at once.

For saving the changes done press button „Save“ to discard the changes press button „Cancel“.

Leaving the menu with „Back“.

Remark: Secondary address “ID” is not changeable the ID is fixed.

Settings → M-Bus → Baudrate

Possible values are 2400, 4800 and 9600 Baud (Default setting = 2400).

M-Bus

Adr: 1 Baudrate: 4800

ID: 123456

☐ Units as String

Save Cancel

Baudrate change by pressing the button „OK“

For saving the changes done press button „Save“ to discard the changes press button „Cancel“.

Leaving the menu with „Back“.

13.4.2 Coding VIF (Value Information Field)

The screenshot shows the 'M-Bus' configuration window. It has fields for 'Adr' (set to 1), 'Baudrate' (set to 2400), and 'ID' (set to 123456). There is a checkbox labeled 'Units as String' which is currently unchecked. A 'Back' button is at the bottom right.

This screenshot is identical to the one above, but the 'Units as String' checkbox is now checked. Additionally, 'Save' and 'Cancel' buttons have appeared at the bottom of the window.

The Sensor offers two possibilities for coding the Value Information Field (VIF).

- Primary VIF (The units and multiplier correspond to MBus specification 4.8 chapter 8.4.3)
- Plain text VIF ((units are transmitted as ASCII characters. So units that are not included in MBus specification chapter 8.4.3 are possible)

Download:

<https://m-bus.com/downloads>

Switch to Plain Text VIF by activation of „**Units as String**“.

13.4.3 Default Settings communication

Primary Address*: 1
 ID: Serial number of Sensor
 Baud rate*: 2400
 Medium*: depending on medium (Gas or Compressed Air)
 Manufacturer ID: CSI
 VIF coding: Primary VIF

Both addresses, Primary address and ID, could be searched in the M-Bus system automatically.

13.4.4 Default values transmitted

Value 1 with [Unit]*: Consumption [m³]
 Value 2 with [Unit]*: Flow [m³/h]
 Value 3 with [Unit]*: Gas temperature [°C]

*All Values could be changed / preset in production or with CS Service software (Order-No. 0554 2007)

14 Error messages

- **Low Voltage**

If the supply voltage is less than 18V, the warning message „**Low Voltage**“ is displayed. This means that the sensor can no longer work / measure correctly and thus there are none measured values for flow, consumption and speed are available.

- **Internal Error**

In the case of this message „**Internal Error**“, the sensor has an internal read error on e.g. EEPROM, AD converter etc. detected.

- **Temp out of Range**


At media temperatures outside the specified temperature range, the status message „**Temp out of Range**“ occurs.

This temperature overshoot leads to incorrect measurement values (outside the sensor specification).

- **Low Voltage 4-20mA**

For sensors with a galvanically isolated 4-20mA output, a min. Supply voltage of 17.5V is required. If this value is undershot, the error message „**Low Voltage 4-20mA**“ is displayed.

Error messages:



15 Supplementary Documentation

- Supplementary Documentation for Ex-Version:

Flow / Consumption Sensor VD 550 Ex / VD5 70 Ex - Ex-Documentation

16 Declaration of Conformity

KONFORMITÄTSERKLÄRUNG
DECLARATION OF CONFORMITY

Wir CS Instruments GmbH & Co.KG
We Gewerbehof 14, 24955 Harrislee

Erklären in alleiniger Verantwortung, dass das Produkt
Declare under our sole responsibility that the product

Verbrauchs-/ Durchflusssensor VD 550
Flow Sensor VD 550

den Anforderungen folgender Richtlinien entsprechen:
We hereby declare that above mentioned components comply with requirements of the following EU directives:

Elektromagnetische Verträglichkeit Electromagntic compatibility	2014/30/EU 2014/30/EC
RoHS (Restriction of certain Hazardous Substances)	2011/65/EC & 2015/863/EC

Angewandte harmonisierte Normen:
Harmonised standards applied:

EMV-Anforderungen EMC requirements	EN 55011:2016 + A2:2021-04 EN 61326-1: 2013-07
RoHS (Restriction of certain Hazardous Substances)	EN IEC 63000:2018

Das Produkt ist mit dem abgebildeten Zeichen gekennzeichnet.
The product is labelled with the indicated mark.



Harrislee, den 22.04.2024


Wolfgang Blessing Geschäftsführer