

## CS Service Software - for VA 5xx flow meters

... incl. PC connection set, USB connection and interface adapter to the sensor.



The flow meters VA 5xx can be connected to the PC, and the following settings can be made by means of the CS Service Software:

- Selection of gas type (air, CO2, N2O, N2, O2, NG, Ar, CH4)
- Selection of units for flow, speed, temperature, consumption
- $\bullet \qquad \text{Selection of units: } m^3/h, \ Nm^3/h, \ m^3/min, \ Nm^3/min, \ Itr/h, \ Nltr/h, \ Itr/min, \ Nltr/min, \ Itr/s, \ Nltr/s, \ cfm, \ SCFM, \ kg/h, \ kg/min, \ kg/s$
- Setting of the reference temperature, reference pressure
- · Zero-point adjustment, leak flow volume suppression adjustable
- Modbus and M-Bus settings
- Scaling of the 4...20 mA analogue output
- Reading of: Version number, production date, series no., time of last calibration
- Setting of alarm limits
- Offset settings (flow offset, temperature offset)
- · Reset factory settings
- Load updates onto the sensor (firmware update, language update)