

INSTALLATION der SERVICE SOFTWARE: Deutsche Version

1. Schritt

Kopieren Sie bitte den gesamten Ordner „**SFA300_Deutsch**“ von der CD auf Ihren PC.

2. Schritt

Installieren Sie den Treiber für die Schnittstellenbox.

Hinweise hierzu finden Sie auf der CD, in der Datei

"InstallationsHilfe Treiber SchnittstellenBox.pdf".

Wenn der Treiber richtig installiert ist, leuchtet bei Anschluss an eine USB-Schnittstelle die gelbe LED auf.

3. Schritt

Starten Sie die ausführbare Datei SFA300DE.EXE aus dem Ordner.

4. Schritt

Der erste Schritt nach dem Start der Software ist die Eingabe des richtigen COMPorts unter „Einstellungen“.

Siehe hierzu Bedienungsanleitung SFA.

INSTALLATION of SERVICE SOFTWARE: English Version

1. Step

Copy the complete folder “SFA300_English” on your PC.

2. Step

Install the driver for the Interface box.

Read the instruction of how to install the USB driver

"InstallationGuide Driver InterfaceBox.pdf"..

If the USB driver is installed properly, the yellow LED will light up whenever the device is connected to a USB port.

3. Step

Start the executable file “SFA300EN.EXE” from the folder.

4. Step

After starting the service software, please select the assigned COM-Port first. Then follow the steps in the instruction manual.