

INSTRUCTION MANUAL

6

VA 409 Flow direction switch for compressed air systems





TABLE of CONTENT

1	FORWORD			
2	SAF	FETY INSTRUCTIONS	4	
3	DES	SCRIPTION	5	
4	TEC	CHNICAL DATA	6	
5	DR	AWING OF THE INSTRUMENT/INSTRUMENTS DIMENSIONS	7	
6	INS	TALLATION DESCRIPTION		
7	SER	RVICE INFORMATION	9	
8	WIF	RING DIAGRAMS	10	
8	3.1	1 Consumption sensor VA 400 and flow direction switch VA 409		
8.2		Consumption sensor VA 420 and flow direction switch VA 409	11	
8.3		2x Consumption sensor VA 400 and flow direction switch VA 409		
8.4		2x Consumption sensor VA 420 and flow direction switch VA 409		
8	3.5	2x Consumption sensor VA 500 / VA 520 and flow direction switch VA 409	14	
8	8.6	Consumption sensor VA 400/VA 420 and flow direction switch VA 409 to DS400		
8.7		2 x consumption sensor VA 400 / VA 420and flow direction switch VA 409 to DS400		
8	8.8	2x consumption sensor VA 500 / VA 520and flow direction switch VA 409 to DS400		
9	WA	RRANTY		
10	ORI	DERING DATA		
11	COI	NFORMITY DECLARATIONS	19	
12	COl	NTACT		



1 FORWORD

Dear CS customer,

You have made the right decision by choosing a measuring instrument from CS Instruments GmbH. Thousands of customers buy our high standard products every year. There are a few good reasons for doing so:

- The cost-performance ratio reliable quality at a fair price.
- We have the ideal solutions for your measuring tasks based on our expert experience gained over 20 years.
- Our high quality standard.
- Of course, our instruments carry the CE symbol required by the EU.
- We issue calibration certificates and hold seminars.
- Also after the purchase we do not leave you out in the cold we offer a good after sales service.



Our service guarantees fast help.

Measuring instrument conforms with DIN EN 61326



2 SAFETY INSTRUCTIONS

Please read carefully before starting the device!

Warning:

Do not exceed the pressure range of 16 bar. From 10 bar we recommend to use the highpressure protection for a safe installation and removal.

Observe the measuring ranges of the sensor!

Overheating destroys the sensor.

Observe the admissible storage and transportation temperature as well as the permitted operating temperature (e.g. protect the instrument from direct insolation).

Always observe the direction of flow when positioning the sensor!

The safety ring at the sensor head must always remain undamaged and sit correctly on the destined thread.

The screwed fixture must be pressure tight.

The adapter sleeve must be tightened with a torque of 20 to 30 Nm.

It is absolutely necessary to avoid condensation on the sensor element or water drops in the measuring air as they may cause wrong results.

The values of the inlet and outlet sections must not fall below the specified minimum values.

The manufacturer cannot be held liable for any damage that occurs as a result of nonobservance or non-compliance with these instructions. Should the device be tampered with in any matter other than a procedure that is described and specified in the manual, the warranty is cancelled and the manufacturer is exempt from liability.

The device is destined exclusively for the described application.

CS Instruments GmbH offers no guarantee for the suitability for any other purpose and is not liable for errors that may have slipped into this operation manual. CS Instruments GmbH is also not liable for consequential damage resulting from the delivery, capability or use of this device.

We offer you to take back the instruments of the instruments family VA 409 which you would like to dispose of.

Adjustments and calibrations should only be carried out by qualified employees from the measurement and control technology branch.



3 DESCRIPTION

VA 409 flow direction switch for compressed air systems

The new thermal flow direction switch VA 409 with direction indication serves for detection of the flow direction of compressed air and gases especially in closed circular pipelines.

By means of VA 409 with direction indication the flow direction of the compressed air will be detected quickly and safely. Compared with the former mechanical paddle flow switches VA 409 detects even the smallest changes in the flow direction quickly and without mechanical movement.

The direction information in form of a potential-free contact (opener max. 60 VDC, 0.5 A) is transferred to the consumption sensors VA 400/VA 420 or to a separate building management system (bms). Two LEDs show the flow direction.

In connection with two consumption sensors, VA 400/VA 420 incoming and outflowing compressed air in closed circular pipelines can be measured precisely.

Special features

- detects smallest changes from < 0.1 m/s referred to 20 °C and 1000 mbar
- no mechanical wear parts
- easy installation under pressure



If there is no flow both direction LEDs are switched off.



4 TECHNICAL DATA

Reaction range recognition flow direction:	< 0.1 m/s referred to 20 °C and 1000 mbar
Measuring principle:	calorimetric measurement
Sensor:	Pt30/Pt700/Pt330
Measuring medium:	Air, gases
Operating temperature:	0 50 °C probe tube -20 70 °C housing
Operating pressure:	up to 16 bar
Power supply:	24 VDC, 40 mA
Power input:	max. 80 mA at 24 VDC
Protection class:	IP 54
EMV:	according to DIN EN 61326
Connection:	2 x M 12, 5-pole, plug A and plug B
2 potential-free switch contacts:	2 x U max. 60VDC, I max. 0.5 A (normally closed) On request: Normally open
Housing:	Polycarbonate
Probe tube:	Stainless steel 1,4301, length 160mm, Ø 10mm Safety ring Ø 12mm Longer probes on request
Mounting thread:	G 1/2"
Diemater housing:	65 mm



5 DRAWING OF THE INSTRUMENT/INSTRUMENTS DIMENSIONS



Connector plug B

Connector plug A

		Pin 1	Pin 2	Pin 3	Pin 4	Pin 5
	Connector plug A	GND -VB 0 V	of flow dire	ben in case action from the right	NC	+24 VDC +VB
VA 409	Connection cable A 0554.0104 (5 m) 0554.0105 (10 m)	brown	white	blue	black	grey
	Connector plug B	NC	Contact open in case of flow direction from the right to the left		NC	NC

GND, -VB	Negative supply voltage 0 V
+VB	Positive supply voltage 1230 VDC smoothed
Pin 2, Pin 3Opener, contact opens from < 0.1 m/s, max. 60 VI	
NC	Not connected

If no connection cable ($0553\ 0104,\ 05530105$) is ordered the sensor will be supplied with two M12 connector plugs.

The user can connect the supply and signal cables as indicated in the connection diagram.



M12 Connector plug A



Connector plug



6 INSTALLATION DESCRIPTION

Instruction for installation of the flow direction switch VA 409

Please read before putting into operation!

- 1. Do not exceed pressure range > 16 bar
- 2. Observe flow direction of the flow direction switch, see direction arrows
- 3. The clamping sleeve must be tightened with a torque of 20 to 30 Nm
- 4. From the view of the flow direction of the gas the flow direction switch has to be installed behind the consumption sensors VA 400/VA 420/VA 500/VA 520
- 5. Please observe minimum distance 5 x Di (inner diameter) to the consumption sensor VA 400/VA 420/VA 500/VA 520.
- 6. The flow direction switch should be installed into horizontal pipelines.

By installation in vertical piplines, measurment errors at mico flow towards rising pipeline results from the self-heating of the sensor,



Attention:

To avoid flow turbulences always install the flow direction switch VA 409 behind the consumption sensors VA 400/VA 420/VA 500/VA 520.

Assembly instructions

Safety information must be observed.

Assembly is carried out by inserting the connection thread (1/2" thread, SW 32) into the connection piece. The sensor is then inserted to the required immersion depth and aligned according to the direction of air flow. A depth scale engraved on the probe tube, a flow alignment arrow and an aligning device will be of help to you. Once the sensor has been aligned, the adapter sleeve must be tightened with the stipulated torque (SW 17).

Attention: Alignment of the sensor must not be modified when tightening the connection thread and adapter sleeve. In this case please check the immersion depth and alignment again and correct if necessary. The angular deviation should not be greater than $\pm 2^{\circ}$ in relation to the ideal position as otherwise the measuring accuracy will decrease.



7 SERVICE INFORMATION

Maintenance

The sensor head should be checked regularly for dirt and cleaned if necessary. Should dirt, dust or oil accumulate on the sensor element, a deviation will occur in the measuring value. An annual check is recommended. Should the compressed air be heavily soiled this interval must be shortened.

Cleaning of the sensor head

The sensor head can be cleaned by carefully moving it to and fro in warm water with a small amount of washing-up liquid. Avoid physical intervention on the sensor (e. g. using a sponge or brush). If soiling cannot be removed, service and maintenance must be carried out by the manufacturer.

Spare parts and repair

For reasons of measuring accuracy, spare parts are not available. If parts are faulty, they must be sent to the supplier for repair. If the measuring device is used in important company installations we recommend to keep a spare measuring system ready.



8 WIRING DIAGRAMS













8.3 2x Consumption sensor VA 400 and flow direction switch VA 409





8.4 2x Consumption sensor VA 420 and flow direction switch VA 409







$8.5 \hspace{0.5cm} 2x \hspace{0.1cm} Consumption \hspace{0.1cm} sensor \hspace{0.1cm} VA \hspace{0.1cm} 500 \hspace{0.1cm} / \hspace{0.1cm} VA \hspace{0.1cm} 520 \hspace{0.1cm} and \hspace{0.1cm} flow \hspace{0.1cm} direction \hspace{0.1cm} switch \hspace{0.1cm} VA \hspace{0.1cm} 409 \hspace{0.1cm}$





$8.6 \qquad \text{Consumption sensor VA 400/VA 420 and flow direction switch VA 409 to DS400}$









8.8 2x consumption sensor VA 500 / VA 520and flow direction switch VA 409 to DS400



9 WARRANTY

If you have reason for complaint we will of course repair any faults free of charge if it can be proven that they are manufacturing faults. The fault should be reported immediately after it has been found and within the warranty time guaranteed by us. Excluded from this warranty is damage caused by improper use and non adherence to the instruction manual.

The warranty is also cancelled once the instrument has been opened - as far as this has not been mentioned in the instruction manual for maintenance purposes - or if the serial number in the instrument has been changed, damaged or removed.

The warranty time for the VA 409 is 12 months. If no other definitions are given the accessory parts have a warranty time of 6 months. Warranty services do not extend the warranty time.

If in addition to the warranty service necessary repairs, adjustments or similar are carried out the warranty services are free of charge but there is a charge for other services such as transport and packaging costs. Other claims, especially those for damage occurring outside the instrument, are not included unless responsibility is legally binding..

After sales service after the warranty time has elapsed

We are of course there for you even after the warranty time has elapsed. In case of malfunctions please send us the instrument with a short-form description of the fault. Please do not forget to indicate your telephone number so that we can call you in case of any questions.

Order no.	Description
0695.0409	Flow direction switch VA 409
0554.0108	Mains unit in wall housing
0553.0104	Connection cable for VA/FA Series 400, 5 m with M12 plug
0553.0105	Connection cable for VA/FA Series 400, 10 m with M12 plug
0695.4001	Consumption sensor VA 400 without display including plug
Options:	
Z695.4000	Display for VA 400
Z695.4003	Max. version VA 400 (185 m/s)
Z695.4002	High-Speed version VA 400 (224 m/s)
ZSL.0120	VA 400 sensor length 120 mm
ZSL.0160	VA 400 sensor length 160 mm
ZSL.0220	VA 400 sensor length 220 mm
ZSL.0300	VA 400 sensor length 300 mm
ZSL.0400	VA 400 sensor length 400 mm
0500.4000 D	DS 400 Display, wall mountable

10 ORDERING DATA



11 CONFORMITY DECLARATIONS

EC Declaration of Conformity

for

DIRECTIVE 2002/96/EC OF THE EUROPEAN PARLIAMENT AND OF THE COUNCIL of 27. January 2003 on waste electrical and electronic equipment (WEEE)

and

DIRECTIVE 2002/95/EC OF THE EUROPEAN PARLIAMENT AND OF THE COUNCIL of 27. January 2003 on the restriction of the use of certain hazardous substances in electrical and electronic equipment (RoHS)

for the following instruments of CS Instruments GmbH:

Pressure dew point meters:	FA 400, FA 410, FA 415, FA 416, FA 300-1, FA 300-2, FA 300-2 Ex, FA 200-2 and accessories
Flow and consumption meters, flow direction switch	VA 300, VA 400, VA 409, VA 410, VA 420, DS 300 and accessories

CS Instruments GmbH as the manufacturer herewith declares that the above instruments and accessories belong to the category 9 (WEEE 2002/96/EC). Therefore the above instruments are not affected by the directive RoHS 2002/95/EC and by the material restriction.

In accordance with directive WEEE 2002/96/EC the measuring instruments specified above will be taken back from CS Instruments GmbH for disposal.

CS Instruments GmbH

Harrislee, 27 March 2007

The Management

th. MMB

This declaration does not guarantee any product characteristics. Please do also adhere to the safety instructions stated in the enclosed documentation.



CS Instruments GmbH

Declaration of Conformity

Flow direction switch for compressed air VA 409

CS Instruments GmbH as the manufacturer herewith declares that the above flow direction switch complies with the following directives :

Electro-magnetic compliance	2004/108/EG
Low voltage directive	2006/95/EG

For assessing the instrument, the following standards have been referred to:

Electromagnetic compatibility	
Emitted interference:	EN 61326-1: 2006-10 + EN 61326-1/Ber.1: 2008-0
Interference resistance:	EN 61326-1: 2006-10 + EN 61326-1/Ber.1: 2008-07
Low voltage derective	
Reliability	EN 61010-1: 2002-08 + EN 61010-1/Ber.1:2002-11 + EN 61010-1/Ber.2:2004-01

CS Instruments GmbH Zindelsteiner Str. 15 78052 VS-Tannheim

Phone: +49 (0)7705 978 99-0 Fax: +49 (0)7705 978 99-20 Tannheim, 19. May 2010

Wolfgang Blessing, Managing Director

This declaration does not guarantee any procuct characteristics. Please do also adhere to the safety instructions stated in the enclosed product documentation.





KONFORMITÄTSERKLÄRUNG

DECLARATION OF CONFORMITY

Wir We

CS Instruments GmbH Am Oxer 28c, 24955 Harrislee

Erklären in alleiniger Verantwortung, dass das Produkt Declare under our sole responsibility that the product

Multi-Messgerät DS400

Multifunction measuring instrument DS 400

den Anforderungen folgender Richtlinien entsprechen: We hereby declare that above mentioned components comply with requirements of the following EU directives:

Elektromagnetische Verträglichkeit	2014/30/EU
Electromagntic compatibility	2014/30/EC
Niederspannungsrichtlinie	2014/35/EU
Low Voltage Directive	2014/35/EC

Angewandte harmonisierte Normen:

Harmonised standards applied:

EMV-Anforderungen EMC requirements	EN 61326-1: 2006-10 2013-07 EN 61000-3-2 : 2015-3	
Sicherheitsanforderungen Safety requirements	EN 61010-1:2015-04	

Anbringungsjahr der CE Kennzeichnung: 13

Year of first marking with CE Label: 13

Das Produkt ist mit dem abgebildeten Zeichen gekennzeichnet. The product is labled with the indicated mark. CE

Harrislee, den 19.04.2016

Wolfgang Blessing Geschäftsfüh



Sales office SOUTH

Zindelsteiner Str. 15 D-78052 Villingen-Schwenningen

> Tel. +49 (0) 7705 97 89 9-0 Fax +49 (0) 7705 97 89 9-20

> > info@cs-instruments.com www.cs-instruments.com

Sales office NORTH

Am Oxer 28c D-24955 Harrislee

Tel. +49 (0) 461 700 20 25 Fax +49 (0) 461 700 20 26

info@cs-instruments.com www.cs-instruments.com