



## Calibration of dew point sensors

The calibration range for dew point sensors is from -112 to 68 °Ftd

Both dew point sensors from us and from other manufacturers can be calibrated. High precision reference measuring devices with DKD or BAM certificate guarantee an accuracy of up to 0.1 °F dew point.

### Special feature:

Due to the digital data transmission, only the dew point sensor has to be calibrated. The display devices remain wired on site.



**Calibration range:** from -80 to 20 °Ctd -  
**Accuracy of the DKD reference:** 0.1 °Ctd



## Control and calibration set

Control and calibration sets provide a defined humidity over a saturated saline solution.

The control and calibration set is screwed onto the dew point sensor and therefore enables an easy and low-priced possibility for on-site control and calibration down to -4 °F dew point.

### DESCRIPTION

- Recalibration and precision calibration at -40...37.4 °Ftd incl. ISO certificate
- Precision calibration in the range -112 to 68 °Ftd, °Ctd points freely selectable
- Control and calibration set 11.3% RH
- Control and calibration set 33% RH
- Control and calibration set 75.3% RH
- Precision calibration at -40...37.4 °Ftd incl. ISO certificate
- Replacement unit for the period of re-calibration
- Pressure dew point replacement sensor from our device pool including precision certificate at -40 °Ftd

### ORDER NO.

- 0699 3333
- 0700 7710
- 0554 0002
- 0554 0004
- 0554 0005
- 0699 3396
- 0699 3900
- 0699 3990