



Dew point set DS 52 for desiccant driers

Consisting of:

- Digital process meter DS 52 (0500 0009)

- Standard measuring chamber

- Option alarm unit
(buzzer and continuous red light)
(Z500 0003)

- Dew point sensor FA 510 (0699 0512-0005)



Special features:

- System ready for plug-in: Everything completely wired
- No time-consuming studying of the instruction manual
- 2 alarm contacts (230 VAC, 3 A) pre- and main alarm freely adjustable
- 4...20 mA analogue output
- Option alarm unit: Buzzer and continuous red light

Technical data display DS 52:

Dimensions:	118 x 92 x 93 mm
Display:	LED red, 7 segments, height: 13 mm, 5 digits, 2 LED for alarm relay
Keypad:	4 keys
Input:	4...20 mA
Power supply:	230 VAC, 50/60 Hz; Option: 24 VDC or 110 VAC 50/60 Hz
Alarm outputs:	2 x relay output, changeover contact, 250 VAC, max. 3 A
Operating temperature:	-10...+60 °C (storage temp. -20°C...+80°C)
Alarm thresholds:	freely adjustable
Hysteresis:	2 °Ctd
Analogue output:	4...20 mA = -60...30 °Ctd

The measuring range of -60...30°Ctd makes the dew point set DS 52 with alarm the ideal dew point monitor with analogue output 4...20 mA.

The dew point sensor FA 510 is extremely long-term stable and can be installed and removed quickly and easily under pressure by means of the screwable measuring chamber including quick coupling. The dew point set is supplied ready for plug-in, i.e. everything is completely wired. The alarm values can be freely adjusted.

Technical data dew point sensor FA 510

Measuring range:	-60...30°Ctd
Accuracy:	± 1°C at 0...20°Ctd ± 2°C remaining range
Pressure range:	-1...50 bar special version up to 350 bar
Protection class:	IP 65
EMV:	according DIN EN 61326
Operating temp.:	-20...70 °C
Connection:	M12, 5-pole
PC connection:	Modbus-RTU interface (RS 485)
Burden for analogue output:	< 500 Ω
Screw-in thread:	G 1/2"

Description	Order No.
Dew point set DS 52 for desiccant driers consisting of:	0600 5120-0005
DS 52 LED display in wall housing	0500 0009
FA 510 dew point sensor for desiccant driers -60...30°Ctd incl. inspection certificate, 4...20 mA output signal (3-wire connection)	0699 0512-0005
Standard measuring chamber up to 16 bar	0699 3390
Connection cable for VA/FA sensors, 5 m	0553 0104
Options:	
Power supply 24 VDC (instead of 230 VAC)	Z500 0001
Power supply 110 VAC (instead of 230 VAC)	Z500 0002
Alarm unit mounted at wall housing	Z500 0003
Alarm unit for external mounting with 5 m cable	Z500 0004
Additional accessories:	
Precision calibration at 3° Ctd including ISO certificate	0699 3396